

QUICK START GUIDE

GDM-904X

GDM-9041/GDM-9042

EN










This Quick Start Guide contains proprietary information, which is protected by copyright. All rights are reserved. No part of this Quick Start Guide may be photocopied, reproduced or translated to another language without prior written consent of Good Will company.

The information in this Quick Start Guide was correct at the time of printing. However, Good Will continues to improve products and reserves the rights to change specification, equipment, and maintenance procedures at any time without prior notice.

S SAFETY INSTRUCTIONS

Safety Symbols

These safety symbols may appear in the user manual or on the instrument.

	Warning	Warning: Identifies conditions or practices that could result in injury or loss of life.
	Caution	Caution: Identifies conditions or practices that could result in damage to the instrument or to other properties.
		DANGER High Voltage
		Attention Refer to the Manual
		Protective Conductor Terminal
		Earth (ground) Terminal
		Do not dispose electronic equipment as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased.

GETTING STARTED

Main Features

Performance • The highest DCV accuracy: 0.02%

- The highest current: 10A
 - The highest voltage: 1000V
 - The highest ACV frequency response: 100 kHz
-

Features

- 50000 count display
 - Multi functions: ACV, DCV, ACI, DCI, R, C, Hz, Temp*, Continuity, Diode test, MAX/MIN, REL, dBm, Hold, MX+B, 1/X, REF%, dB, Compare.
 - Manual or Auto ranging
 - AC true RMS
 - Data Logging to USB*
 - Data logging to PC using an Excel Add-In
-

Interface

- USB device/ GPIB (optional)
 - USB device port supports USB CDC and USB TMC
 - USB Host for GDM-9042
-

Software

- Excel Addins
-




Note

- *These features are only available on the GDM-9042
-


Appearance

Front Panel Overview



Description	
1. Power Switch	2. Main Display
3. Measurement Keys	4. AC/DC Current Input Terminals
5. HI and LO Input Terminals	6. USB Host Port
7. ESC (Escape) Key	8. Screenshot / Data log Key
9. Auto Range/Enter Key	10. Arrow Keys
11. Function keys (F1 through F6, functions vary per modes)	

Rear Panel Overview




Description

1. Current Fuse Box	2. USB Connector (B Type)
3. GPIB Connector (optional)	4. Alternate Input Switch
5. AC Mains Input (Power Cord Socket)	6. AC Mains Line Voltage Selector and Fuse Socket

STATUS BAR

Background Identify each icon within the top status bar.

Status Bar
Display



Item	Description
------	-------------

- | | |
|---|--|
| 1 | Local / Remote control icon |
| 2 | USB-CDC / USB-TMC / GPIB interface icon |
| 3 | Error icon for commands from remote control |
| 4 | Shift key identification icon |
| 5 | The first and second function menu switch icon |
| 6 | Auto Identification for input source measurement |
| 7 | USB flash drive connection icon |
| 8 | Beep / Key Sound setting icon |
| 9 | Time display |


START UP

Power Up

Steps

1. Before the power is turned on, confirm the input power supply meets the following conditions:

100 V/120 V/220 V/240 V $\pm 10\%$, 50/60 Hz




2. The fuse is a slow-blow fuse.

T 0.16 A (220 V/240 V),
T 0.315 A (100 V/120 V)

Confirm that the fuse is of the correct type and rating before connecting the power cord.




3. Connect the power cord to the AC Voltage input.



Note

Make sure the ground connector on the power cord is connected to a safety ground. This will affect the measurement accuracy.


4. Push the power button until click to turn on the main power switch on the front panel.



5. The screen firstly shows the logo brand of GWINSTEK followed by the message "Load the parameter [Last] is ok" indicating the last parameter is loaded in the initial startup.


Set Up

Horizontal/Tilt/Vertical Application




Pull out the handle sideways and rotate clockwise for the applications below.

Horizontal




Place the unit horizontally.

Tilt



Rotate the handle for tilt stand.

Vertical




Place the handle vertically for hand carry.

BASIC MEASUREMENT OVERVIEW

Background

Basic measurement refers to several types of measurements assigned to the upper 2 row keys on front panel.



Measurement type

ACV	AC Voltage
DCV	DC Voltage
ACI	AC Current
DCI	DC Current
Ω 2W	2-wire Resistance
•))	Continuity
FREQ \leftarrow	Frequency/Capacitance
TEMP \rightarrow	Temperature/Diode

Advanced measurement

Advanced measurement mainly refers to the operation using the result obtained from one or more of the basic measurements.

Refresh Rate

Background

Refresh rate defines how frequently the GDM-9041/9042 captures and updates measurement data. A faster refresh rate yields a lower accuracy and resolution. A slower refresh rate yields a higher accuracy and resolution. Consider these tradeoffs when selecting the refresh rate.

Measurement Type Refresh Rate Available

DCV/DCI/ 2W	5/s	40/s	160/s
ACV/ACI	5/s	40/s	160/s
Continuity / Diode	10/s	40/s	160/s
Frequency & Period	1s	100ms	10ms
Capacitance	2/s		
Temperature	5/s	40/s	160/s

Selection Procedure Press the left or right Arrow keys to change the refresh rate.




Also, press the F2 (Speed) key to select a desired refresh rate. Press corresponding function key in accord with the desired option on display.

Speed




The refresh rate will be shown at the upper right corner of the display. See the example below.




Note

The refresh rate cannot be set for capacitance measurement.

Reading indicator

The reading indicator , which is in the lower-right corner of display, flashes according to the defined refresh rate setting.



Reading Indicator


Internal (Automatic) Triggering

Overview By default, the GDM-9041/9042 automatically triggers measurement according to the set refresh rate. See the previous page for refresh rate setting details. The TRIG key, on the other hand, can be used to manually trigger once per click.

SIN (Manual) Trigger Simply press the TRIG key to SIN trigger mode, which signifies manual triggering measurement. Pressing once stands for trigger for single time.



Indicator SIN Trigger Mode




INT (Auto) Trigger Press and hold the TRIG key for 2 seconds to change to INT (Auto) trigger mode, which stands that automatic triggering measurement per refresh rate.



(Press & hold for 2 seconds)

Indicator INT (Auto) Trigger Mode




Note


SIN triggering is not supported for capacitance measurements.

Test Leads Connection


ACV/DCV Connect the test lead between the Input HI and Input LO terminals. The display updates the reading.




ACI/DCI Connect the test lead between the 10A terminal and the COM terminal or DC/AC 0.5 A terminal and the COM terminal, depending on the input current. For current ≤ 0.5 A use the 0.5 A terminal; For current up to 12 A use the 10 A terminal. The display updates the reading.




2W For 2W measurement, connect the test leads between the Input HI terminal and the LO terminal.




Diode Connect the test lead between the Input HI terminal and the LO terminal; Anode-V, Cathode-COM. The display updates the reading.




Frequency In terms of current, connect test leads between the 0.5 A terminal and the LO terminal or DC/AC 10 A terminal and the LO terminal. The display updates the reading.




Period In terms of current, connect test leads between the 0.5 A terminal and the LO terminal or DC/AC 10 A terminal and the LO terminal. The display updates the reading.



Capacitance Connect the test lead between the Input HI terminal and the LO terminal; Positive-HI, Negative-LO. The display updates the reading.



Temperature Connect the sensor lead between the Input HI terminal and the LO terminal. The display updates the reading.



SPECIFICATIONS

- Calibration: Yearly
- Operating Temperature Specification: 18 to 28 °C (64.4 to 82.4 °F)
- Relative Humidity: 80% (Non condensing)
- Accuracy: \pm (% of Reading + Digits)
- AC measurements are based on a 50% duty cycle.
- The power supply cable must be grounded to ensure accuracy.
- All specifications are applicable to the main (1st) display only.

General Specifications

Specification Conditions:

Temperature: 23 °C \pm 5 °C

Humidity: <80% RH, 75% RH for resistance measurement readings greater than 10 M Ω .

Operating Environment: (0 to 50 °C)

Temperature Range: 0 to 35 °C, Relative Humidity: <80% RH; >35 °C, Relative Humidity: <70% RH

Indoor use only

Altitude: 2000 meters

Pollution degree 2

Storage Conditions (-10 to 70 °C)

Temperature Range: 0 to 35 °C, Relative Humidity: <90% RH; >35 °C, Relative Humidity: <80% RH


General:

Power Consumption: Max 30 VA


Dimensions: 268 mm x 107 mm x 302 mm

Weight: Approximately 3.2 kg

Dimension



All dimensions are shown in millimeters.



Declaration of Conformity

We
 GOOD WILL INSTRUMENT CO., LTD.
 declare that the below mentioned product
 satisfies all the technical relations application to the product within the scope of council:
 Directive: EMC; LVD; WEEE; RoHS
 The product is in conformity with the following standards or other normative documents

© EMC	
EN 61326-1 :	Electrical equipment for measurement, control and laboratory use — EMC requirements
Conducted & Radiated Emission EN 55011 / EN 55032	Electrical Fast Transients EN 61000-4-4
Current Harmonics EN 61000-3-2 / EN 61000-3-12	Surge Immunity EN 61000-4-5
Voltage Fluctuations EN 61000-3-3 / EN 61000-3-11	Conducted Susceptibility EN 61000-4-6
Electrostatic Discharge EN 61000-4-2	Power Frequency Magnetic Field EN 61000-4-8
Radiated Immunity EN 61000-4-3	Voltage Dip/ Interruption EN 61000-4-11 / EN 61000-4-34
© Safety	
EN 61010-1 :	Safety requirements for electrical equipment for measurement, control, and laboratory use - Part 1: General requirements

GOODWILL INSTRUMENT CO., LTD.

No. 7-1, Jhongsing Road, Tucheng District, New Taipei City 236, Taiwan
 Tel: [+886-2-2268-0389](tel:+886-2-2268-0389) Fax: [+886-2-2268-0639](tel:+886-2-2268-0639)
 Web: <http://www.gwinstek.com> Email: marketing@goodwill.com.tw

GOODWILL INSTRUMENT (SUZHOU) CO., LTD.

No. 521, Zhujiang Road, Snd, Suzhou Jiangsu 215011, China
 Tel: [+86-512-6661-7177](tel:+86-512-6661-7177) Fax: [+86-512-6661-7277](tel:+86-512-6661-7277)
 Web: <http://www.instek.com.cn> Email: marketing@instek.com.cn

GOODWILL INSTRUMENT EURO B.V.

De Run 5427A, 5504DG Veldhoven, The Netherlands
 Tel: [+31-\(0\)40-2557790](tel:+31-(0)40-2557790) Fax: [+31-\(0\)40-2541194](tel:+31-(0)40-2541194)
 Email: sales@gw-instek.eu