

PC Software

LCR-8200Series

PC Software Guide

VERSION: 1.00



ISO-9001 CERTIFIED MANUFACTURER

GW INSTEK

This manual contains proprietary information, which is protected by copyrights. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will company.

The information in this manual was correct at the time of printing. However, Good Will continues to improve products and reserves the right to change specifications, equipment, and maintenance procedures at any time without notice.

Good Will Instrument Co., Ltd.

No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.

T ABLE OF CONTENTS

INTRODUCTION.....	4
SETUP.....	5
Install PC software	5
Install USB Driver	6
Configuration	8
Connection	10
LCR METER	13
FILE.....	14
Test procedure management.....	14
SETUP.....	16
System setup.....	16
MODE.....	17
HELP.....	22
QUIT.....	23

INTRODUCTION

This manual is suitable for all models in the LCR-8200 Series. The LCR Meter PC Software Guide describes how to use the PC software on Windows OS based computers (Windows 10, Windows 7 supported).

This manual consists of the following chapters:

- Setup: Installation, Configuration, Connection
- TEST MODE/EDIT MODE: Edit step measurement parameters, executing step measurement and logging step measurement results.

Software Overview

Step	Freq	Level	First	1-P/F	Second	2-P/F	Third	3-P/F	Fourth	4-P/F	AC-Vm	AC-Im	DC-Vm	DC-Im
1	1kHz	1V	459.4551n		29.2860m		98.6164m		97.4536m		1.0001m	10.1121m	4.0657m	41.6583m
2	10kHz	1V	477.1580n		304.4448m		102.9393m		97.0784m		1.0597m	10.1205m	4.0435m	41.6255m
3	100kHz	1V	476.0481n		2.9741		315.5655m		96.9695m		3.2924m	10.1224m	4.0414m	41.6243m
4	500kHz	1V	463.7968n		11.3691		1.4816		97.0047m		15.5994m	10.1205m	4.0425m	41.6243m
5	1MHz	1V	463.3234n		16.0454		2.9163		96.9206m		30.7245m	10.1292m	4.0343m	41.6224m
6	5MHz	1V	450.3715n		41.1204		14.1530		96.9070m		155.3213m	10.5932m	4.0412m	41.6198m
7	10MHz	1V	446.3454n		61.0334		28.0485		97.0026m		347.2912m	12.0989m	4.0440m	41.6223m
8	15MHz	1V	446.1968n		52.9886		42.0606		96.9121m		574.7028m	13.6113m	4.0442m	41.6470m
9	20MHz	1V	446.1964n		44.7079		56.0847		96.8206m		595.8169m	10.8830m	4.0351m	41.6411m
10	25MHz	1V	444.0379n		37.2382		69.7745		96.7157m		498.2727m	7.5939m	4.0309m	41.6540m
11	30MHz	1V	438.4721n		36.4651		82.6811		96.7617m		416.0996m	5.6196m	4.0308m	41.6449m

Test Mode
 All Step

GW INSTEK,LCR-8230,GET000002,1.35 USB:COM5

SETUP

Install PC software

The following describes how to install the LCR-8200 PC software and software suite on your PC.

PC system requirements:

1. CPU 1GHz
2. LCD: 1024x768
3. HD: 1GB
4. RAM: 4GB
5. OS: Win10/Win7
6. CD-ROM


-
- | | |
|-----------------|--|
| Installing step | <ol style="list-style-type: none">1. Go to the PC Software directory on the CD-ROM.2. Click on setup.exe. |
|-----------------|--|



- | | |
|--|--|
| | <ol style="list-style-type: none">3. The installation wizard will start up. Follow the directions from the installation wizard. When choosing an install location it is recommended that the default location is chosen. |
|--|--|

The default location for the software is C:\LCR Meter.


A program icon should be available from the Start Menu.



- After the installation has completed, a shortcut icon for the LCR Meter software will be added to your desktop.




- Click on dotnetfx35.exe. Setup .NET Framework 3.5 suite. It is unnecessary for additional setting during installation process. Click “Next” to complete.



It is available to download the file from link below:
<https://www.microsoft.com/en-us/download/developer-tools.aspx>

- Click on NIVISA1750full.exe. Setup NI-VISA17.5 suite. It is unnecessary for additional setting during installation process. Click “Next” to complete.



It is available to download the file from link below:
<https://www.ni.com/zh-tw/support/downloads/drivers/download.ni-visa.html>

Install USB Driver


The USB driver needs to be installed when using the USB port for remote control. The USB interface creates a virtual COM port when connected to a PC. Simply skip this installation process if not adopting USB Port for PC connection control.

Installing step

- Install the USB VCP Driver (zadig-2.4.exe) from the CD



- Execute the Zadig program.




- Connect the Type A-B USB cable to the rear panel USB B port on the LCR-8200Series. Connect the other end to the Type A port on the PC.



- The Zadig software will detect the LCR-8200, select CDC, and press “Install Driver” to install the driver.



- Successful installation.



- The LCR-8200 and the COM port that it is assigned to will now appear under the Ports (COM & LPT) node.



- Install the USB VCP Driver (zadig-2.4.exe) from the CD

Configuration

The device uses the GPIB/ LAN/ RS-232/ USB interface to communicate with the computer to complete all devices' functions. Before initiating the PC connection between the PC software and a LCR-8200, first set and confirm the SYSTEM CONFIG interface settings on the LCR-8200.

GPIB Interface

The computer and the measuring instrument are connected with GPIB cable (such as GW Instek's GTL-248), and the test piece will be tested on the computer through GPIB port, 24 pins.

Prior to connection, ensure that GPIB ADDRESS setting is identical to PC software setting

<SYSTEM CONFIG>	
GPIB ADDRESS	7
RS232 BAUD RATE	115200
RS232 EOI	CR+LF
LAN PORT	OFF
HANDLER INTERFACE	OFF
KEY BEEP	OFF

LAN Interface

10/100 Base Ethernet, 8 pins. The instrument will be connected to the LAN (Local Area Network) ports.

Set ON for LAN PORT and go to LAN SETUP to set network relevant settings. Or use AUTO followed by inserting network cable for auto setup. Prior to connection control, ensure that PC software IP setting is identical to CURRENT IP ADDRESS.

<SYSTEM CONFIG>	
GPIB ADDRESS	7
RS232 BAUD RATE	115200
RS232 EOI	CR+LF
LAN PORT	ON
HANDLER INTERFACE	OFF
KEY BEEP	OFF

LAN SETUP	
IP CONFIG	AUTO
MAC ADDRESS	00:08:DC:47:00:20
LAN STATUS	CONNECTED PORT 111
CURRENT IP ADDRESS	192.168. 31. 80
CURRENT SUBNET MASK	255.255.248. 0
CURRENT GATEWAY	192.168. 31.254
CURRENT DNS SERVER	172. 16. 1.252

RS-232C Interface

The RS-232C serial interface can be connected to the serial interface of a controller (PC or IPC) through a RS-232C cable (null modem, such as GW Instek's GTL-232).

Make sure that parameter of RS232 BAUD RATE setting is identical to PC software. Set RS232 EOI as LF.

<SYSTEM CONFIG>	
GPIB ADDRESS	7
RS232 BAUD RATE	115200
RS232 EOI	LF
LAN PORT	OFF
HANDLER INTERFACE	OFF
KEY BEEP	OFF

USB Interface

The Type B USB port on the rear panel is used USB cable (A-B type, such as GW Instek's GTL-246) for remote control. This interface creates a virtual COM port (CDC) when connected to a PC.

The EOI of LCR-8200 return info will utilize the RS232 EOI set parameter.

<SYSTEM CONFIG>	
GPIB ADDRESS	7
RS232 BAUD RATE	115200
RS232 EOI	LF
LAN PORT	OFF
HANDLER INTERFACE	OFF
KEY BEEP	OFF

Connection


Open the PC software and connect the control cord to LCR-8200 in one end and PC side in the other end. Set software connection parameters followed by proceeding to measurement control.

Configure PC Software


1. Activate the PC software.



2. Click on the Setup/Communication menu and open the setting dialog.




3. Select one of the connection methods to proceed to parameters setup.



4. Click on the Connection button. The PC software and the LCR-8200 will try to establish a connection (success), or an error message appears (fail).


Success `GW INSTEK,LCR-8230,GET000002,1.35 PORT:COM1 BAUD:11520`

Fail



The possible reasons of connection failure:

- Wrong interface port or pattern settings.
 - Wrong wiring in the cable or the connectors of the cable are not well connected.
5. When connection is established, the model, serial number, FW version and control interface info of connected unit will be shown from LCR Meter software. The LOCK icon will be displayed in the lower-right corner from LCR-8200 LCD display, which signals that the unit is under connection control and thus the panel keys are not available.



LCR Meter

The operation setting of PC software is identical with that of LCR-8200. It is the test method which integrates the Meter mode with LIST mode and provides the function of test log recording.



Note

Before connecting the LCR meter to the software, remember to perform the Correction first. The PC software doesn't have the ability to perform the Open/Short correction. These functions can only be performed on the meter itself.

Edit Mode

Step	Freq	Level	Speed	DC Bias	AC-Range	DC-Range	Trig Delay	AC/DC Delay	Average	ALC	RO	1-Func	1-Comp Mode	1-Standard	1-High	1-Low	2-Func	2-Comp Mo
1	1kHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
2	1...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
3	1...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
4	5...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
5	10Hz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
6	50Hz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
7	1...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
8	1...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
9	2...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
10	2...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
11	3...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF

Test Mode


Step	Freq	Level	First	1-P/F	Second	2-P/F	Third	3-P/F	Fourth	4-P/F	AC-Im	AC-Im	DC-Im	DC-Im
1	1kHz	1V	483.4300n		38.6559m		95.1272m		95.7631m		1.0050m	10.1120m	3.9790m	41.4751m
2	10kHz	1V	479.1855n		384.4812m		183.5413m		95.8201m		1.0650m	10.1119m	3.9730m	41.4570m
3	100kHz	1V	478.6103n		2.9766		317.2361m		95.8614m		3.3873m	10.1138m	3.9772m	41.4487m
4	500kHz	1V	472.1455n		11.3676		1.4890		95.8767m		15.0500m	10.1110m	3.9739m	41.4480m
5	1MHz	1V	465.6929n		16.8591		2.9312		95.9072m		38.8419m	10.1182m	3.9786m	41.4466m
6	5MHz	1V	452.6579n		41.4870		14.2248		95.7998m		155.9746m	10.5560m	3.9782m	41.4546m
7	10MHz	1V	448.7397n		62.8521		28.1987		95.9371m		349.3122m	12.1874m	3.9853m	41.4593m
8	150kHz	1V	448.8335n		55.0313		42.3895		96.8028m		576.8726m	11.5911m	3.9871m	41.4623m
9	200kHz	1V	449.8310n		47.1210		56.4396		95.8724m		594.8953m	10.7979m	3.9750m	41.4648m
10	250kHz	1V	447.1265n		39.4841		78.2570		95.8694m		496.0860m	7.5115m	3.9804m	41.4638m
11	300kHz	1V	441.7490n		39.7821		83.2948		95.8545m		414.8928m	5.5557m	3.9806m	41.4693m

File

Test procedure management


Open File/Save File

It loads test procedure from PC and also saves current test procedure.




Open File

When loading test procedure, the default directory is C:\LCR Meter. It only supports the file format (csv) saved by LCR Meter software.



Save File

When saving the currently edited test procedure, the default directory is C:\LCR Meter. The file format to save is csv file.



Test procedure file (csv).


Step	Freq	Level	speed	DC Bias	AC-Range	DC-Range	Trig Delay	AC/DC De	Average	ALC	EO	1-Func	1-Comp	M-I-Standard	1-High	1-Low	2-Func	2-Con
1	1 kHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	100	LS	OFF	0	0	0	Q	OFF
2	10 kHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	100	LS	OFF	0	0	0	Q	OFF
3	100 kHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	100	LS	OFF	0	0	0	Q	OFF
4	500 kHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	100	LS	OFF	0	0	0	Q	OFF
5	1 MHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	100	LS	OFF	0	0	0	Q	OFF
6	5 MHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	100	LS	OFF	0	0	0	Q	OFF
7	10 MHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	100	LS	OFF	0	0	0	Q	OFF
8	15 MHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	100	LS	OFF	0	0	0	Q	OFF
9	20 MHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	100	LS	OFF	0	0	0	Q	OFF
10	25 MHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	100	LS	OFF	0	0	0	Q	OFF
11	30 MHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	100	LS	OFF	0	0	0	Q	OFF

Setup

System setup


Communication Setting

Connection communication interface parameters setting.



Setting

Select communication interface of connection and set the relevant parameters.




M mode

PC software controls LCR-8200 to utilize Meter mode for measurement.


Edit Mode/Test Mode

Click Edit Mode to enter the test steps editing page.
Click Test Mode to enter the test procedure measurement page.



Edit Mode

Identical to the operation of LCR-8200, up to 4 test items and test parameters can be set for each test step, which can set range judgment for measured value. While measuring, it will follow steps order for measurement.



Step display

At the maximum of 200 steps can be set for test steps display area.

Step	Freq	Level	Speed	DC Bias	AC-Range	DC-Range	Trig Delay	AC/DC Delay	Average	ALC	RO	1-Func	1-Comp Mode	1-Standard	1-High	1-Low	2-Func	2-Comp Mo
1	1kHz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
2	1...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
3	1...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
4	5...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
5	10Hz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
6	50Hz	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
7	1...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
8	1...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
9	2...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
10	2...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF
11	3...	1V	MED	0	AUTO	AUTO	0	0	1	OFF	1	LS	OFF	0	0	0	Q	OFF

Setup

Refer to the user manual of LCR-8200 for more detailed info of each parameter.

- Freq.: measure frequency.
- Level: measure signal voltage/current level.
- Speed: measure speed.
- DC BIAS: DC Bias value.
- AC-Range: AC measure range.
- DC-Range: DC measure range.
- Trig Delay: delay time before each measure.
- AC/DC Delay: delay time before each RDC measure.
- Average: multiple measurements and take an average result.
- ALC: automatic level control on/off.
- RO: output impedance.

Freq.	<input type="text" value="1"/>	KHZ
Level	<input type="text" value="1"/>	V
Speed	<input type="text" value="MED"/>	
DC Bias	<input type="text" value="0"/>	V
AC-Range	<input type="text" value="AUTO"/>	
DC-Range	<input type="text" value="AUTO"/>	
Trig Delay	<input type="text" value="0"/>	ms
AC/DC Delay	<input type="text" value="0"/>	ms
Average	<input type="text" value="1"/>	
ALC	<input type="text" value="OFF"/>	
RO	<input type="text" value="100"/>	


Function/Comparison

- 1~4-Func: measure parameter item.
- 1~4-Comp Mode: comparison function. (values, Δ tolerance values and Δ tolerance %)
- 1~4-standard: compare nominal values. Set only in the Δ and $\Delta\%$ modes.
- 1~4-High: comparison of upper limit.
- 1~4-Low: comparison of lower limit.

1-Func	<input type="text" value="LS"/>	
1-Comp Mode	<input type="text" value="VALUE"/>	
1-Standard	<input type="text" value="0"/>	H
1-High	<input type="text" value="500.0000"/>	nH
1-Low	<input type="text" value="400.0000"/>	nH
2-Func	<input type="text" value="Q"/>	
2-Comp Mode	<input type="text" value="Δ"/>	
2-Standard	<input type="text" value="1.0000"/>	
2-High	<input type="text" value="1.0000"/>	
2-Low	<input type="text" value="-1.0000"/>	
3-Func	<input type="text" value="Z"/>	
3-Comp Mode	<input type="text" value="Δ%"/>	
3-Standard	<input type="text" value="100.0000"/>	mΩ
3-High	<input type="text" value="10.0000"/>	%
3-Low	<input type="text" value="-10.0000"/>	%
4-Func	<input type="text" value="RDC"/>	
4-Comp Mode	<input type="text" value="OFF"/>	
4-Standard	<input type="text" value="0"/>	Ω
4-High	<input type="text" value="0"/>	Ω
4-Low	<input type="text" value="0"/>	Ω


 Button

- Add step: if not selecting edited step from the test steps display area, a test step will be newly added from set parameter when clicking button.
- Modify step: if selecting edited step from the test steps display area, each parameter of the selected step will be shown in the set area. After setting new parameters, click the button to take the test step setting into effect.
- Insert step: Click to select a step in the test steps display area. After setting parameters, click the button to insert a test step before the selected step.
- Copy step: Click the button to show the copy steps window. After setting, click OK button to create a copied step.
 - Start: Start step
 - End: End step
 - Destination: Target step
 - Front: Create copied step before the target step.
 - Back: Create copied step after the target step.
- Delete step: Click to select a step in the test steps display area. Click the button to delete the selected step.
- Delete All: Delete all steps.



Test Mode

Connect to LRC-8200 to utilize Meter mode for measurement. It follows the steps order when measurement is ongoing.



Test result

When test finishes, the test row shows value with blue in background to indicate the value has been updated from the test result display area.

Step	Freq	Level	First	1-P/F	Second	2-P/F	Third	3-P/F	Fourth	4-P/F	AC-Vm	AC-Im	DC-Vm	DC-Im
1	1KHz	1V	404.1227n	Pass	25.8400m	Pass	98.2981m	Pass	96.8296m	Fail	999.6115u	10.1272m	4.0400m	41.6912m
2	10KHz	1V	397.2044n		253.5718m		101.5371m		96.9146m		1.0593m	10.1275m	4.0436m	41.6785m
3	100KHz	1V	396.5211n		2.4793		268.6433m		96.8547m		3.2935m	10.1274m	4.0399m	41.6668m
4	500KHz	1V	390.0973n		9.4303		1.2324		97.0182m		15.6061m	10.1247m	4.0416m	41.6638m
5	1MHz	1V	383.6319n		14.0521		2.4165		97.0045m		30.7395m	10.1329m	4.0427m	41.6620m
6	5MHz	1V	375.3639n		43.6924		11.7955		97.0493m		155.3180m	10.5924m	4.0445m	41.6533m
7	10MHz	1V	387.0332n		176.6740		24.3184		97.0436m		346.9734m	12.0882m	4.0424m	41.6755m
8	15MHz	1V	399.1940n		57.5955		37.6288		97.0021m		573.9527m	13.5934m	4.0413m	41.6713m
9	20MHz	1V	672.1149n		20.8272		04.5578		97.0094m		596.4160m	10.8041m	4.0430m	41.6820m
10	25MHz	1V	1.0501u		8.8639		165.3099		97.0502m		499.4615m	7.5904m	4.0422m	41.6719m
11	30MHz	1V	-780.9544n		319.0942m		484.2430		97.0030m		417.3545m	5.6234m	4.0419m	41.6763m

Freq.: measure frequency.

Level: measure signal voltage/current level.


First~Fourth: measured value of 1~4-Func.

1~4-P/F: Comparing results of 1~4-Func.

AC-Vm/Im: test signal voltage/current of the AC on the test object..

DC--Vm/Im: test signal voltage/current of the DC on the test object..


- Test Mode/Button
- Test Mode: Test mode for step(s).
 - All: The entire steps.
 - Step: Input a designated step in the blank box for test
 - Start: Start test.
 - Stop: Finish test.
 - Log save as: Save measured value and test steps as .csv file.
 - Remove All: Erase the entire measured values.
-



Help

About

Version number of the LCR Meter software.



Quit

Click the X sign in the upper-right corner from LCR Meter software to finish and exit. The software will reconfirm again with prompt message.

