

# 韌體升級

GLC-10000



## 韌體升級手冊

This firmware update manual contains proprietary information, which is protected by copyrights. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will company.

The information in this manual was correct at the time of printing. However, Good Will continues to improve products and reserves the rights to change specification, equipment, and maintenance procedures at any time without notice.

Good Will Instrument Co., Ltd.  
No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.



ISO-9001 CERTIFIED MANUFACTURER

**GW INSTEK**

## 升級程序

GLC-10000 的韌體升級需要，USB 2.0 隨身碟以及對應型號的韌體檔。



注意

更新時用的韌體檔名“LC1XR.BIN”，與原始定義檔名不同，使用前請先複製到隨身碟的根目錄下，再手動修改。例如：

原始檔名 ~ GLC10000\_V1.03\_20230101\_LC1XR.BIN

手動修改 ~ LC1XR.BIN

### 升級步驟

1. 關閉 GLC-10000 電源
2. 插入具有更新檔“LC1XR.BIN”的 USB 隨身碟 (檔案必須直接存於根目錄下).
3. 按住 STOP 鍵(如下圖所示)不放，然後開啟 GLC-10000 電源.



4. 機器自動進入升級模式，並開始更新.



5. 更新完成後，機器會自動重新啟動。更新後的機器版本，請至 System 下的“Information”確認。