High Voltage Adapter Box

GHT-117

GWINSTEK

User Manual GW INSTEK PART NO. 82HT-11700MC1

This assembly manual contains proprietary information, which is protected by copyrights. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will company.

The information in this manual was correct at the time of printing. However, Good Will continues to improve products and reserves the rights to change specification, equipment, and maintenance procedures at any time without notice.

Good Will Instrument Co., Ltd. No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.



ISO-9001 CERTIFIED MANUFACTURER



GHT-117

The GHT-117 High Voltage Adapter Box is an optional accessory of the GPT series Electrical Safety Analyzer/Tester aimed at providing a convenient way to connect the DUT's AC line socket to the analyzer/tester for the AC withstanding, DC withstanding and Insulation Resistance tests.

Consideration

🕂 Warning

The GPT series Electrical Safety Analyzers/Testers operate at up to 5kVAC and 6kVDC. To prevent electrical shock, the grounding wire of the adapter box (green/yellow wire) must be connected to the ground connector of the GPT series rear panel. Please also make sure that the GPT series is properly grounded via its AC line input. Please refer to the specific GPT series User Manual for more information regarding safety and the earth ground connection.

Connection



- 1. Connect the red wire to the High Voltage terminal HIGH VOLTAGE Terminal of the GPT series.
- 2. Connect the white wire to the Return terminal of the GPT series.
- 3. Connect the green/yellow wire to the GND terminal at the rear panel of the GPT series.







Internal connection

Universal Type	The AC plug L and N terminals are shorted and connected to the red HV wire.	
	The AC plug GND terminal is connected to the white Return wire. The adapter's case is connected to the green/yellow GND wire.	
EU Type	The AC plug L and N terminals are shorted and connected to the red HV wire. The AC plug GND	GND CAUTION HIGH VOLTAGE
	terminal is connected to the white Return wire.	
	The adapter's case is connected to the green/yellow GND wire.	

Dimensions



Applicable Device

Series	Models
GPT-15000 Series	GPT-15001/GPT-15002/GPT-15003
GPT-12000 Series	GPT-12001/GPT-12002/GPT-12003
GPT-9900/9900A Series	GPT-9901A/GPT-9902A/GPT-9903A/GPT-9903
GPT-9800 Series	GPT-9801/GPT-9802/GPT-9803
GPT-9600 Series	GPT-9601/GPT-9602/GPT-9603/GPT-9612