

GPM-8320/8330

Digital Power Meter

FEATURES

• 5" TFT LCD

- Voltage/Current Meter Test Freq. Bandwidth: DC, 0.1Hz ~ 100kHz
- Waveform Display : V (Voltage), I (Current), P (Wattage)
- Distorted wave Current/Voltage Measurement: Full Range for CF=3, and Half Range for CF=6 (or 6A)
- Meeting IEC 61000-4-7 Harmonic Measurement (50/60Hz)
- Wiring Selecting Button (1P3W, 3P3W, 3P4W, 3V3A)
- Harmonic Measurement & Analysis up to 50 Orders
- Auto Ranging Function for Integration Mode
- Screen Capture Through USB Host
- Provide External Current Sensor Input (EXT1/EXT2)
- Standard Interface: RS-232C, USB Device/Host, LAN
- Optional Interface: GPM-DA12 GPIB + Digital I/O (Factory Installed Only)



GW Instek GPM-8320/8330 are digital power meters designed specifically for measuring power in three-phase AC power sources, making it suitable for most electrical and electronic product testing applications (GPM-8320 provides 2 modules, and GPM-8330 provides 3 modules). These models have a testing bandwidth of DC, 0.1Hz~100 kHz and feature 16-bit A/D converters and a sampling rate of 300 kHz. A 5-inch TFT LCD display, 5 digits of measurement readings, 25 different power measurement parameters, and high precision measurement capabilities are also provided. GPM-8320/8330 also feature waveform display capabilities (voltage/current/power), the integration measurement function, harmonics measurement and analysis of multiple orders (50/60Hz measurement complies with IEC61000-4-7 requirements), external sensor input terminals, and a variety of communications interfaces. These features help users achieve clear, convenient, and accurate power measurements, making them the most fully-featured and cost-effective power meters in the same category.

GPM-8320/8330 provide multiple input voltage configuration wiring modes (1P3W/3P3W/3P4W/3V3A). Users can choose the wiring mode according to their specific requirements to measure parameters for specific wiring methods, and even calculate efficiency. In addition, for a rated input voltage of 1000V and an input current of 20A, they support a minimum current range of 0.5A (resolution of 0.1mA), power measurement resolution of 0.1mW, crest factor of 3 (for half range, the CF can reach up to 6 or 6A), and voltage/current/power measurement accuracy of ±0.1% reading ±0.05% range. Users can select different measurement modes (AC+DC/AC/DC/V-MEAN) to provide up to 25 related parameters for power measurement. These parameters include voltage (Vrms/Vac/Vdc/Vmn/V+pk/V-pk), current (Irms/Iac/Idc/I+pk/I-pk), frequency (VHz/IHz), power (P/P+pk/P-pk), crest factor (CFV/CFI), apparent power (VA), reactive power (VAR), power factor (PF), phase angle (DEG), total harmonic distortion (THDV/THDI), maximum current ratio (MCR), and MATH calculation function. Therefore, they provide the best range and accuracy support for measuring the power consumption of electrical and electronic products.

GPM-8320/8330 also effectively utilize the advantages of TFT LCD display, providing results of parameter measurements in both numerical and graphical formats. In terms of numerical display, it offers a general mode and a multiple mode. The general mode includes 4 tabs (page1~page4), and each tab can display 10 measurement parameters (2 main measurements + 8 monitoring measurements). Users can freely combine these parameters to display the results of measurements from various modules. The multiple mode can simultaneously display the measurement results of three modules, which is particularly suitable for comparing differences in measurements between modules, such as unbalanced three-phase. This mode also offers 4 tabs, and each tab can display 8 measurement parameters. In terms of graphical display, they offer a simple oscilloscope mode to display voltage, current, and power parameters in waveform format. Additionally, the display provides numerical or bar chart display for the measurement and analysis of harmonics signals at various orders that not only satisfies the need for accuracy and clear readability in process testing, but also meets the diverse measurement application requirements for research and development, design and quality verification.

GPM-8320/8330 have comprehensive mechanisms and functions for auxiliary measurements. For applications that require measuring high voltage, they provide VT rate settings that can be used with external potential transformers. For measuring large current, it depends on the type of current transformer, whether it is a voltage output type or a current output type. If it is a current output type, it can be directly locked onto the meter's rear panel and used with CT rate settings for measurement. If it is a voltage output type, it can be measured through the external current sensor input terminals (EXT1/EXT2) provided by GPM-8320/8330. Automatic range switching can be customized to the required range to save unnecessary time spent on range switching. The internal memory of 10,000 data logs can store measurement data at the update rate set by GPM-8320/8330 or at a user-defined time interval for future analysis.

In terms of data acquisition and storage, GPM-8320/8330 offer a variety of communications interfaces, including RS-232C/USB device (virtual COM)/LAN, or optional GPIB. Users can choose to write programs to read measurement results according to their habits or in collocation with existing system interfaces. The USB host can support screen capture, internal data logging, and firmware updates for GPM-8320/8330. For those with the needs of using external signal control or data recorder for data recording, GPM-8320/8330 also offer an optional Digital I/O (DA12) interface (must be installed at the factory), which can be connected to external controllers such as PLC or data recorders to meet the needs of automated measurements or long recording applications.

A. WIRING SELECTION



GPM-8320/8330 provide multiple input voltage configuration wiring modes (1P3W/3P3W/3P4W/3V3A). Users can choose the wiring mode according to their specific requirements to measure parameters for specific wiring methods, and even calculate efficiency.



B. VARIOUS DISPLAY MODES



Numerical (Single) Mode

С

Numerical (Multiple) Mode

Numerical (Simple) ModeMode Waveform Mode Harmonics (Bar Graph) Measurement

Harmonics (List) Measurement

GPM-8320/8330 provide two display modes, numerical and graph, which help users maximize the benefits of their measurements. In numerical mode, there are two options: single and multiple. In single mode, there are four tabs that can be customized with the module's measurement settings, and each tab can display up to 10 measurement parameters (2 main and 8 secondary measurements). In multiple mode, there are also four tabs, and users can simultaneously observe the same 8 measurement parameters from three different modules. Parameters in both modes can be arranged and customized as needed, and a simple mode that displays only the first four parameters is also available regardless of which tab is selected. In graph mode, there is a simple oscilloscope function that displays the waveforms of three parameters: voltage, current, and power. The horizontal scale can be adjusted (from 50us/div to 10ms/div depending on the set data update rate), and three waveform observation magnification ratios are available. When measuring harmonics, the harmonics measurement results of each order can be displayed in a bar chart, and a specific observation order can be specified. Additionally, all relevant values for harmonics of each order (voltage/current/power voltage distortion percentage/current distortion percentage/power distortion percentage/voltage phase angle/current phase angle) can be fully recorded and presented.

RICH MEASUREMENT PARAMETERS

Measurement Items	Symbols
Voltage	Vrms, V+pk, V-pk, Vac*, Vdc*, Vmn*
Current	Irms, I+pk, I-pk, Iac*, Idc*
Power	P, P+pk, P-pk, VA, VAR
Power Factor	PF
Crest Factor	CFV, CFI
Phase Angle	DEG
Frequency	VHz, IHz
Total Harmonic Distortion	THDV, THDI
Mathematical Computation	MATH
Maximum Current Ratio	MCR
Integration	WP, WP+, WP-, q, q+, q-, Vac, lac

*: Only applicable to specific measurement modes and available for selection

GPM-8320/8330 provide a variety of measurement items, including voltage, current, frequency, active power, apparent power, reactive power, power factor, crest factor, total harmonic distortion, and even the ability to measure maximum current ratio. Additionally, GPM-8320/8330 are equipped with measurement functions for power or current time integration specific to the DUT. Users set a period of time to perform

Mode	M	anual		
Function	W	att Hours		
Set Time		000:00:	:00	
Test Time		000:01:	21	
State	R	unning		
	Element1	Element2	Element3	Σ
WP[Wh]	10.039	10.039	10.052	30.130
WP+[Wh]	10.039	10.039	10.052	30.130
WP-[Wh]	-0.0000m	-0.0000m	-0.0000m	-0.0000m
Maasura	Set	Flement		

instantaneous power integration during this time, and then divide by the time to obtain the average power of the DUT. Moreover, during integration measurements, GPM-8320/8330 support automatic range switching function to obtain the most complete integration results in response to the power changes of the DUT in different time periods.

SUPERB MEASUREMENT ASSISTANCE



Ratio Configuration

In terms of measurement support, GPM-8320/8330 perform exceptionally well. Firstly, in the measurement of high voltage/power, they provide voltage/power ratio settings to restore the attenuation rate to the true value. In addition, for large current measurement, other than the current ratio setting, there are also terminals (EXT1/EXT2) for external current sensors that can be connected to voltage output type current transformers, making large current measurement more convenient.



External Current Sensor Input

Furthermore, GPM-8320/8330 provide 4 sets of panel settings for storage/recall and a memory that can store up to 10,000 measurements. The measurement storage can record the measurement results according to the update rate or a user-defined time interval for later analysis. The USB host on the front panel supports screen capture, measurement value storage, and firmware updates.

Ε.

FLEXIBLE LEVEL-CHANGING MECHANISM



Automatic level-changing under the integration function

GPM-8320/8330 offer automatic range switching mode for integral measurement, allowing users to calculate the total value of the DUT's power variation from the start to the end of the integration period. In

MEASUREMENT RANGE CONFIG On Mode Quick Skipping Config On V-Range 00 150V 300V 600V 600V Veak Over Off 00 I-Range 10A 0.5A 10A SA 10A Peak Over Off

Self-defined automatic level-changing mechanism

addition, GPM-8320/8330 also support a customizable range switching mechanism. Users can select the desired range, which not only saves time wasted during range switching but also speeds up the testing process.

F. CONVENIENT AND PRACTICAL INTERFACE



Practical Interface

GPM-8320/8330 offer a comprehensive and diverse set of communications interfaces, including RS-232/USB/LAN/GPIB (optional), suitable for users to remotely control and collect measurement results through command sets to program computer software. The optional Digital I/O (DA12) interface provides three different modes according to users' settings: including external control, DA12 output, and self-defined output. When the setting is external control mode, users can activate, stop, trigger, or reset the integration measurement function through



DA12 Interface Mechanism

external signals. When it is set to DA12 output mode, users can define 12 measurement parameter values from the provided 17 measurement parameters (even the result of integration measurement) to output in a fixed range (full scale +5V) or manual range (full scale \pm 5V) and receive the results in collocation with a data recorder. When it is set to custom output mode, it needs to be used with a communications interface, and the action of each defined pin is controlled through commands.

PANEL INTRODUCTION



SPECIFICATIONS				
INPUT				
Item	Specifications			
Input Type	Voltage / Current		Floating input through resistive voltage divider; Floating input through shunt	
Measure Range	Voltage		15V, 30V, 60V, 150V, 300V, 600V, 1000V	
	Current Direct input Sensor input		0.5A, 1A, 2A, 5A, 10A, 20A EXT 1: 2.5 V, 5 V, 10 V ; EXT 2: 50 mV, 100 mV, 200 mV, 500 mV, 1 V, 2 V	
Input Impedance	Sensor Input range 2	ange 0.5A ~ 20A 5V ~ 10V (EXT1) 0mV ~ 2V (EXT2)	Input resistance: approach 2 M Ω Input resistance: approach 5 m Ω Input resistance: approach 100 k Ω Input resistance: approach 20 k Ω	
Continuous Maximum Allowable Input	Voltage Current Direct input i Sensor input	ange 0.5A ~ 20A	peak value of 1.5kV or RMS value of 1kV, whichever is less peak value of 100A or RMS value of 30A, whichever is less peak value less than or equal to 5 times of the rated range	
Input Bandwidth	DC, 0.1 Hz ~ 100kHz			
Continuous Maximum	600 Vrms, CAT 🛛			
Common-mode Voltage Line Filter	select OFF or ON (cut of	frequency of EOO H-		
			,	
Frequency Filter A/D Converter	select OFF or ON (cut of			
1			inputs; Resolution 16bits; Maximum conversion rate Approx. 300kHz	
Display Update Interval	When the data update interval is 100 ms the numeric display 10 items display update interval is 200 ms. When the data update interval is 100 ms or 250ms and the numeric value display is set to Matrix or ALL Items display update interval is 500 ms. The waveform display update intervals are approximately 1s.			
VOLTAGE AND CURRENT ACCURACY Item	Specifications			
Requirements	Temperature Humidity Input waveform common-mode voltage Number of displayed digi Frequency filter	0 V ts 5 digits Turn on to rm-up time has passo	H crest factor = 3 measure voltage or current of 200 Hz or less ed; After measurement range is changed (zero-level compensation);	
Accuracy	$\begin{array}{l} DC\\ 0.1 \ Hz \leq f < 45 \ Hz\\ 45 \ Hz \leq f \leq 66 \ Hz\\ 66 \ Hz < f \leq 1 \ HHz\\ 1 \ kHz < f \leq 10 \ kHz\\ 10 \ kHz < f \leq 100 \ kHz\\ Values \ for \ voltage \ in \ excellarge \ excellarge \ in \ excellarge \ excellarge \ in \ excellarge \ in \ excellarge \ excellarge \ excellarge \ excellarge \ in \ excellarge \ excellarge \ in \ excellarge \ exc$	± (0.1 % of reading ± (0.07 *f) % of reading ± (0.5 % of reading	g + 0.2 % of range) g + 0.05 % of range)	
Temperature Coefficient	Add		/°C within the range 5 to 18°C or 28 to 40°C.	
When the Line Flter is Turned ON	45 ~ 66 Hz < 45 Hz	45 ~ 66 Hz Add 0.3% of reading		
Accuracy When the Crest Factor is Sset to 6 or 6A		0	ent range error for the accuracy when the crest factor is set to 3	
Accuracy Changes Caused by Data Update Interval			Auto, add 0.05% of reading to the 0.1 Hz to 1 kHz accuracy.	
Influence of Temperature Changes After Zero-level Compensation or Range Change	Add 0.02% of range/°C to the DC voltage accuracy. Add the following value to the DC current accuracies. 5 mA/10 mA/20 mA/50 mA/100 mA/200 mA ranges 5 μA/°C 0.5 A/1 A/2 A/5 A/10 A/20 A ranges 500 μA/°C External current sensor input (/EXT1) 1 mV/°C External current sensor input (/EXT2) 50 μV/°C			
Accuracy When the Crest Factor is Set to 6 or 6A		0	ent range error for the accuracy when the crest factor is set to 3	
Accuracy Changes Caused by Data Update Interval	When the data update int	erval is 100 ms, and	Auto, add 0.05% of reading to the 0.1 Hz to 1 kHz accuracy.	
ACTIVE POWER ACCURACY Item	Specifications			
Requirements	same as the conditions for Power factor	or voltage and curren	t.	
Accuracy	$\begin{array}{l} DC\\ 0.1Hz \leq f < 45Hz\\ 45Hz \leq f \leq 66Hz\\ 66Hz < f \leq 1kHz\\ 1kHz < f \leq 10kHz\\ 10kHz < f \leq 100kHz\\ \end{array}$	± (0.1 % of readin ± (0.2 % of readin ± (0.1 % of readin	+ 0.2 % of range) g + 0.2 % of range) g + 0.05 % of range) g + 0.2 % of range) g + 0.3 % of range) ± [{0.067x(f-1)}% of reading] g + 0.5 % of range) ± [{0.09x(f-10)}% of reading]	
Influence of Power Factor	when power factor (λ) = ± 0.1 % of S for 45 Hz \leq ± {(0.1 + 0.15 × f) % of S • f is frequency of input si when 0 < λ < 1 (Φ : phase (power reading) × [(pow power value) + {tan Φ × (^F ≤ 66 Hz } for up to 100 kHz gnal in kHz angle of the Voltage er reading error%) +	, as reference data and current) (power range %) × (power range / indicated apparent	

When The Line Filler is Tunnel ON 41: 0. 401 36 of reading Temperature Conflicient 3am as the impartance conflicient for allog and carrent is requested and the inal age of a second of the accuracy of them the sympathy the measurement regime of the accuracy of them the sympathy the measurement regime of the accuracy of them the sympathy accuracy of the sympathy accuracy o	SPECIFICATIONS				
Tomport Confliction Series (Series of Academy Meet The Confliction Series of Academy Meet Top Series (Series Of Academy Meet Top Series Of Academy Meet		45 ~ 66 Hz	Add 0.3 % of reading		
Accuracy When The Certification is solving of plaquent Power 5 exclusion of plaquent power 4 (~ 1.004 / 1.22) * (/		< 45 Hz	8		
Set to 6 ro A. excess of Appanet Power 5 event accurate a	Temperature Coefficient		6		
Accuracy of Apparent Power 3 evaluation of Apparent Power 4 (-1 1004 - 30): (-1 - 123) r0(0 + 1 - 200 - 1001 (-1 - 200 - 100	*		publing the measurement range error for the accu	racy when the crest factor is	
Accuracy of functive Power Q accuracy of appaint power - L ² (2004 - 22) - (2 - 123, 2003 - 2004 - 200					
Accuracy of Power Factar A = (0.471 (0.0027) is case acception: 1 (if linearse from the power factar when 2 = 0.91(0.001) 1 al digit when values and commerts are at the researcement range and power factar when 2 = 0.90(1.001) 1 al digit when values and commerts are at the researcement range and power factar when 2 = 0.90(1.001) 1 al digit when values and commerts are at the researcement range and power factar when 1 the cost factor 1 is set to 3 for 4		а ,	,		
does of the Difference 0 index index and current are ther measurement range rand up at the index index with x = 0.6 k / 100 l = 1 digit when when the dist random when x = 0.6 k / 100 l = 1 digit when when x = 0.6 k / 100 l = 1 digit when when x = 0.6 k / 100 l = 1 digit when when x = 0.6 k / 100 l = 1 digit x = 0.0 k / 100 l =		,			
index when values and current are it the measurement range rank input when values values of bothing the measurement range rank input setto 3 setto 40000 (Softed readows) setto 3 setto 40000 (Softed readows) setto 40000 (Softed readows)<		when voltage and curre	nt are at the measurement range rated input	, ,, ,, ,	
is Set for 6 A set 0.3 means the set of a set 0.3 means 4.0 to .0.39% of reading to the 0.1 Hz to 1 kHz means 4.0 to .0.39% of reading to the 0.1 Hz to 1 kHz means 4.0 to .0.39% of reading to the 0.1 Hz to 1 kHz means 4.0 to .0.39% of reading to the 0.1 Hz to 1 kHz means 4.0 to .0.39% of reading to the 0.1 Hz to 1 kHz means 4.0 to .0.39% of reading to the 0.1 Hz to 1 kHz means 4.0 to .0.39% of reading to the 0.1 Hz to 1 kHz means 4.0 to .0.39% of reading to the 0.1 Hz to 1 kHz means 4.0 to .0.39% of reading to the 0.1 Hz to 1 kHz means 4.0 to .0.39% of reading to the 0.1 Hz to 1 kHz means 4.0 to .0.39% of reading to the 0.1 Hz to 1 kHz means 4.0 to .0.39% of reading to the 0.1 Hz to 1 kHz means 4.0 to .0.39% of reading to .0.39% of re	Accuracy of Phase Difference Φ				
Update interval accuracy Update interval Specifications Measurement Method Dip Us simple method Cest Factor 3 or 6 (A) Wring System Single phase, wowsite (P 2W) Range Selet Single phase, wowsite (P 2W) Cest Factor 3 Wrins or time acceds 130% of the currently set measurement range. Cest facor 3 Cest facor 4 Wrins or time acceds 250% of the currently set measurement range. Cest facor 6 Cest facor 5 Wrins or time acceds 250% of the currently set measurement range. Wrins or time acceds 250% of the currently set measurement range. Wrins or time acceds 250% of the currently set measurement range. Wrins or time acceds 250% of the react set set set set set set set set set se	is Set to 6 or 6A				
Item Specifications Measurement Method Optigal anguing method Crest Factor 3 or 6 (6A). Single-phase, how wite (1 PZ V) Anto-Range Select Anto-Range Select Select manal or anto ranging: Anto-Range Select Crest factor A Orest factor A Wrins or Irms accessed 139% of the currently set measurement range. Verse or Irms accessed 139% of the currently set measurement range. Crest factor A Verse or Irms accessed 139% of the currently set measurement range. Verse or Irms accessed 139% of the currently set measurement range. Verse or Irms accessed 139% of the currently set measurement range. Verse or Irms accessed 230% of the currently set measurement range. Verse or Irms is less than or equal to 125% of the currently set measurement range. Vers or Irms is less than or equal to 125% of the currently set measurement range. Verse or Irms is less than or equal to 125% of the current ly set measurement range. Vers or Irms is less than or equal to 125% of the current ly set measurement range. Verse or Irms is less than or equal to 125% of the current ly set measurement range. Vers or Irms is less than or equal to 125% of the next lower measurement range. Verse or Irms is less than or equal to 125% of the next lower measurement range. Vers or Irms is less than or equal to 125% of the next lower lower measurement range. Pab	Update Interval	accuracy.	nterval is 100 ms, and Auto, add 0.05% of reading	to the 0.1 Hz to 1 kHz	
Messarement Mehod Diplication/line method Orest Factor 3 or 6 (6A) Wring System Single phase, two wrie (1 P2 W) Range Selett Auto-range formasis: The range is upped when ary of the following conditions is met. Auto-range formasis: The range is observed biols of the currently at measurement range. Vipi, Ipi, Julia of the inpit signal access 3005 of the currently set measurement range. Vipi, Ipi, Julia of the inpit signal access 3005 of the currently set measurement range. Vipi, Ipi, Julia of the inpit signal access 3005 of the currently set measurement range. Orest factor 8 Wrms or Irms is less than or equal to 325 of the measurement range. Auto-range factor 8 Wrms or Irms is less than or equal to 305 of the currently set measurement range. Vipi, Ipi value of the inpit signal access 3050 of the currently set measurement range. Vipi, Ipi value of the inpit signal access 3050 of the currently set measurement range. Vipi, Ipi value of the inpit signal access 3050 of the currently set measurement range. Vipi, Ipi value of the inpit signal access 3050 of the currently set measurement range. Display Mode Switching Vrms of trms is less than or equal to 325 of the measurement range. Vipi, Ipi value of the inpit signal access 3050 of the current iy set measurement range. Vipi, Ipi value of value access 3050 of the current iy set measurement range. Display Mode Switching Vrms of trms is less than or		1			
Crest Factor 3 or 6 (6A) Wring System Single-phase, bow rite (1 P2 W) Range Selet Select manual or auto traging Auto Range Crest factor 3 Auto Range Crest factor 3 Auto Range Select manual or auto traging Auto Range Crest factor 3 Crest factor 3 Wrins of Irms exceeds 30% of the currently set measurement range. Vip. Ipk value of the input signal exceeds 60% of the currently set measurement range. Vip. Ipk value of the input signal exceeds 60% of the currently set measurement range. Vip. Ipk value of the input signal exceeds 60% of the currently set measurement range. Vip. Ipk value of the input signal exceeds 60% of the currently set measurement range. Wrins of Irms is less than or equal to 30% of the measurement range. Wrins of Irms is less than or equal to 30% of the measurement range. Wrins of Irms is less than or equal to 30% of the measurement range. Wrins of Irms is less than or equal to 30% of the measurement range. Display Mode Switching Vrms for Irms is less than or equal to 30% of the currently set measurement range. Wrins I will be official and current) Vist Ref trans PS will be official exceeds 40% of the current is set shown or equal to 30% of the measurement range. Display Mode Switching Vrms for Irms exceed faults of the official best faults or equal to 30% of the measurement range. Vist Ref trans PS will be exceed faults of the currently set measurement range. Display Mode Switching<			4		
Wring System Single-phase, how wire (1 P2 W) Range Selet: Selet manual crauto ranging a Lato range rough of the currently set measurement range. Why, lpk value of the inpat sign access 300% of the currently set measurement range. Why, lpk value of the inpat sign access 300% of the currently set measurement range. Crest factor 6. Wrins of time screeces 100% of the currently set measurement range. Crest factor 6. Wrins of time screeces 300% of the currently set measurement range. Crest factor 6. Wrins of times is less than or equal to 20% of the currently set measurement range. Why, lpk value of the inpat sign access 400% of the currently set measurement range. Crest factor 6. Wrins of times is less than or equal to 20% of the currently set measurement range. Why, lpk value of the inpat sign access 400% of the currently set measurement range. Why, lpk value of the inpat sign access 400% of the currently set measurement range. Why, lpk value of the inpat sign access 400% of the currently set measurement range. Why, lpk value of the inpat sign access 400% of the currently set measurement range. Why, lpk value of the inpat sign access 400% of the currently set measurement range. Why, lpk value of the inpat sign access 400% of the currently set measurement range. Why, lpk value of the inpat sign access 400% of the current is set measurement range. Why, lpk value of the inpat sign access 400% of the current is set measurement range. Why, lpk value of the inpat sign access 400% of the current is set measurement range. Wrins value of value set value access 100% of the current is set measurement range. Wrins value of value set value access 500% of the current is set measurement range. Wrins value of values and untern transe value access 500% of the current is set masurement range. Wrins value of value access 500% of the current is set measurement range. Wrins value of values access 500% of the current is set masaret the range s		0 1 0	4		
Range Select Select manual or auto imaging: Auto-range increase: The range is upped when any of the following conditions is met. Creat faces / Wins, of time secoeds 130% of the currently set measurement range. View of time is conded 10% of the currently ext measurement range. View of time secoeds 250% of the currently ext measurement range. Crest faces / 6 Vins or time secoeds 250% of the currently ext measurement range. View of the dist of the input signal exceeds 300% of the currently ext measurement range. View of time secoeds 250% of the currently ext measurement range. View of time signal meased and of the following conditions are met. Crest faces / 6 Vims or time secoeds 250% of the currently ext measurement range. View of time is less than or equal to 25% of the neasurement range. View of time is less than or equal to 12% of the neasurement range. View of time is less than or equal to 12% of the neasurement range. View of time is less than or equal to 12% of the neasurement range. View of view of time is less than or equal to 12% of the neasurement range. View of time is less than or equal to 12% of the neasurement range. View of view of time is less than or equal to 12% of the neasurement range. View of time is less than or equal to 12% of the neasurement range. View fiew time field remeasurement is ange. View of time is less than or equal to 12% of the neasurement range. View field view of t		. ,	1 P2 W)		
Auto Parge increase: The Tange is upped when any of the following condition is met. Crest factor is vins, by vinse of the screent 300% of the currently set measurement range. Crest factor is vins, by vinse of the currently set measurement range. Crest factor is vinse of the currently set measurement range. Vinse of the screent 300% of the currently set measurement range. Crest factor is vinse of the currently set measurement range. Auto-range decline: The range is dewined when all of the following conditions are met. Auto-range decline: The range is dewined when all of the following conditions are met. Auto-range decline: The range is dewined when all of the following conditions are met. Crest factor is reference. Vinse of time is less than or equal to 12% of the measurement range. Vinse of time is less than or equal to 12% of the measurement range. Vinse of time is less than or equal to 12% of the measurement range. Vinse of the input signal exceeds 500% of the currently set measurement range. Vinse of time is less than or equal to 12% of the measurement range. Vinse of time is less than or equal to 12% of the measurement range. Vinse of time is less than or equal to 12% of the measurement range. Vinse of time is less than or equal to 12% of the measurement range. Vinse of time is less than or equal to 12% of the measurement range. Vinse of the currently set measurement range. Vinse of the input signal exceent 500% of the me	••		,		
Parts fach:1 Wins or limits acceeds 100% of the currently set measurement range. Vik, lip Vulue of the input signal acceeds 500% of the currently set measurement range. Cest fachor 6 Vik, lip Vulue of the input signal acceeds 500% of the currently set measurement range. Cest fachor 6 Vik, lip Vulue of the input signal acceeds 500% of the currently set measurement range. Cest fachor 6 Vik, lip Vulue of the input signal acceeds 500% of the currently set measurement range. Cest fachor 6 Vik, lip Vulue of the input signal acceeds 500% of the currently set measurement range. Vik lip Vulue of the input signal acceeds 500% of the currently set measurement range. Vik, lip Vulue of the input signal acceeds 500% of the currently set measurement range. Vik lip Vulue of the input signal acceeds 500% of the currently set measurement range. Vik lip Vulue of the input signal acceeds 500% of the currently set measurement range. Vik lip Vulue of the input signal acceeds 500% of the currently set measurement range. Display Mode Switching Wins of the input signal acceeds 500% of the currently set measurement range. Vick lip Vulue of the input signal acceeds 500% of the currently set measurement range. Vick lip Vulue of the input signal acceeds 500% of the currently set measurement range. Display Mode Switching Wins of the input signal acceeds 500% of the currently set measurement range. Vick input set measurement range. Overote Set Of or ON	5		0 0	tions is met.	
Creat factor 6 Virms or Irms exceeds 130% of the currently set measurement range. Virk, 16/4 vulue of the input signal exceeds 50% of the currently set measurement range. Virk, 16/4 vulue of the input signal exceeds 50% of the currently set measurement range. Virk 16/4 vulue of the input signal exceeds 50% of the currently set measurement range. Auto-range decline: The range is downed when all of the following conditions are met. Crest factor 3 Virms or Irms is less than or equal to 130% of the measurement range. Crest factor 6 Virms or Irms is less than or equal to 130% of the measurement range. Virk, 16/4 vulue of the input signal exceeds 500% of the currently set measurement range. Display Mode Switching Virms or Irms is less than or equal to 130% of the measurement range. Virk 16/4 vulue of the input signal exceeds 500% of the currently set measurement range. Massurement Synchronization Source Select voltage, current, or off In the case of Auto Update Rate, select the voltage and the true RMS vulue of the current) xet MS vulue of the input signal exceeds 500% of the current were measurement range. Massurement Synchronization Source Select voltage, current of power from the instantaneous power that is samplid. Zaro-level Compensation Resurves the internal offset of the measurement range is changed. Massurement Praumeters! Virus of the measurement range is changed. Current Irem Virus of the measurement range. Virus and Virus and Virus And Virus and Virus and	-	Crest factor 3 Vrms	or Irms exceeds 130% of the currently set measu	rement range.	
Creat factor 64 Vms or Imms exceed 260% of the currently set measurement range. Vek, 164 vule of the input signal exceed 300% of the measurement range. Vek, 164 vule of the input signal exceed 300% of the measurement range. Vek, 164 vuls of the input signal exceed 300% of the measurement range. Vek, 164 vuls of the input signal exceed 300% of the measurement range. Vek, 164 vuls of the input signal exceed 300% of the measurement range. Vek, 164 vuls of the input signal exceed 300% of the measurement range. Vek, 164 vuls of the input signal exceed 300% of the measurement range. Vek, 164 vuls of the input signal exceed 300% of the measurement range. Vex input signal exceed 300% of the currently set measurement range. Vex input signal exceed 300% of the currently set measurement range. Vex input signal exceed 300% of the currently set measurement range. Vex input signal exceed 300% of the measurement range. Vex input signal exceed 300% of the measurement range. Vex input signal exceed 300% of the currently set measurement range. Vex input signal exceed 300% of the currently set measurement range. Vex input signal exceed 300% of the measurement range. Vex input		Crest factor 6 Vrms	or Irms exceeds 130% of the currently set measu	rement range.	
Auto-range decline: The range is downed wher all of the following conditions are met. Set factor 3 Vms or tims is less than or equal to 23% of the measurement range. VPk, lpk value of the input signal exceeds 300% of the currently set measurement range. VPk, lpk value of the input signal exceeds 300% of the currently set measurement range. Display Mode Switching Vms of tims is less than or equal to 23% of the measurement range. VPk, lpk value of the input signal exceeds 500% of the currently set measurement range. Vms (the true RMS value of voltage and current) VDTACE MEAN (the rectified mean value calibrated to the RMS value of the voltage and the true RMS value of the currently set measurement range. Vms (the rectified mean value calibrated to the RMS value of the voltage and the true RMS value of the orthoge, current or to the totage and the true RMS value of the orthoge, current or to the voltage or current form the equipped element. Pak Measurement Measurement or instantaneous power fast is sampled. Termeters Resourcement Parametersi Voltage Yms, Vmn, Vdc, Vac frequency Resourcement Parametersi Voltage Vms, Vmn, Vdc, Vac frequency IH2 and VH2 Resourcement Parametersi Voltage and current Vms, Vmn, Vdc, Vac formersion formation in the requency and Vpk Resourcement Parametersi Voltage and current VAR totage and vpk formation in the requency		Crest factor 6A Vrms	or Irms exceeds 260% of the currently set measu	rement range.	
Cest factor 3 Vmm or mis is less than or equal to 25% of the meat lower measurement range. Vpk, lpk value of the input signal exceeds 300% of the currently set measurement range. Vpk, lpk value of the input signal exceeds 300% of the measurement range. Vpk, lpk value of the input signal exceeds 300% of the measurement range. Vpk, lpk value of the input signal exceeds 300% of the measurement range. Vpk, lpk value of the input signal exceeds 500% or termeasurement range. Vpk, lpk value of the input signal exceeds 500% or termeasurement range. Diplay Mode Switching Vmm or terms is less than or equal to 25% of the measurement range. Vpk, lpk value of the input signal exceeds 500% or termeasurement range. Measurement Synchronization Soure Select Voltage, current or UT is the case of Auto Update Rate, select the voltage and the true MS value of the current value calibrated to the RMS value of the evalue of dement. Image: Supprise the pass the pass the pass the pass than or equal to 25% of the current from the equipped element. Image: Supprise the pass the pa				, 0	
Vpk, lpk value of the input signal exceeds 300% of the currenty set measurement range. Vpk, lpk value of the input signal exceeds 300% of the currenty set measurement range. Vpk, lpk value of the input signal exceeds 300% of the currenty set measurement range. Vpk, lpk value of the input signal exceeds 300% of the currenty set measurement range. Vpk, lpk value of the input signal exceeds 300% of the currenty set measurement range. Vpk, lpk value of the input signal exceeds 300% of the currenty set measurement range. Vpt lpk value of the input signal exceeds 300% of the currenty set measurement range. Vpt lpk value of the input signal exceeds 300% of the currenty set measurement range. Vpt lpk value of the input signal exceeds 300% of the currenty set measurement range. Vpt lpk value of the input signal exceeds 300% of the current set measurement range. Vpt lpk value of the input signal exceeds 300% of the current set measurement range. Vpt lpk value of the input signal exceeds 300% of the measurement range. Vpt lpk value of the input signal exceeds 300% of the measurement range. Vpt lpk value of the input signal exceeds 300% of the measurement range. Vpt lpk value of the input signal exceeds 300% of the measurement range. Vpt lpk value of the input signal exceeds 300% of the measurement range. Vpt lpk value of the input signal exceeds 300% of the measurement range. Vpt lpk value of the input signal exceeds 300% of		-	Vrms or Irms is less than or equal to 30% of the	measurement range.	
Crest factor 6 or 6A Wms or trms is less than or equal to 32% of the measurement range. Display Mode Switching Wms or trms is less than or equal to 125% of the next lower measurement range. VPL, lpk value of the input signal acceeds 600% of the currently set measurement range. Wms or trms is less than or equal to 125% of the next lower measurement range. Display Mode Switching Wms or the true RMS value of voltage and current) Measurement Synchronization Source Select voltage, current, or off in the case of Auto Update Rate, select the voltage or current from the equipped element. Line Filter Select Voltage, current, or off the measure one (Auto Update Rate, select the voltage or current from the equipped element. Line Filter Select Voltage, current, or 00 (cutoff frequency at SOD H2). Peak Measurement Reasures the peak (max, min) value of voltage, current or power from the instantaneous voltage, instantaneous current or instantaneous power that is sampled. Zero-level Compensation Reasurement Offset of the measure unit (After measurement range VPA, North Page Peak Vrage Peak Active Power VA VA Value Power Value Power Page And Pizzer VAR Total Harmonic Distortion ThDI and THDV Reasurement Item Specifications Verse Value Power Value Power Value Power Value gand current.			•		
Image: The state of the input signal exceeds 600% of the currently set measurement range. Display Mode Switching Vrms (the true RMS value of Voltage and current) RMS value of the current. Maximum Current Synchronization Source Select Voltage, current. or of In the case of Auto Update Rate, select the voltage and the true voltage. Do Select Voltage, current. or Stote Source to power from the instantaneous voltage. Instantaneous current or instantaneous power that is sampled. Pack Measurement Resources the pack (max, min) value of voltage, current or power from the instantaneous voltage. Instantaneous current or instantaneous power that is sampled. Frequency Notage. Voltage Peak HZ and VHZ Resources the pack (the Work Peak Current Peak Heaver VAR Voltage Peak Voltage Peak Voltage Peak Visp and VpA Voltage Peak Voltage Peak Voltage Autor Voltage Autor Nota Voltage Peak Voltage Peak Visp and VpA Voltage Peak Voltage Voltage Voltage Voltage Voltage Voltage Voltage Voltage Voltage Voltage Voltage Voltage Voltage Voltage Voltage Vol		Crest factor 6 or 6A		•	
VOLTACE MEAN (the rectified mean value calibrated to the RMS value of the voltage and the true RAS value of the current) AC DC Measurement Synchronization Source Select Voltage, current or off In the case of Auto Update Rate, select the voltage or current from the equipped element. Line Filter Select VOIT For ON (cutoff frequency at 500 Hz). Peak Measurement Measures the peak (max, min) value of voltage, current or power from the instantaneous voltage, instantaneous our instantaneous power that is sampled. Zero-level Compensation Removes the internal offset of the measure unit (Afre measurement range is changed). Measurement Parametersl Voltage Vrms, Vrm, Vdc, Vac Frequency IHz and VHz Current Irms, Idc, Iac Voltage Peak V+pk and Ipk P+pk and Ipk Apparent Power VA Active Power Peak P+pk and Ipk Apparent Power VA Active Power Peak P+pk and Ipk Apparent Power VA Active Power Peak P+pk and Ipk Measurement Item Specifications Measurement Frequency Range MATH Notage and current DEG DEG Notage Notage Measurement Frequency Range D1 as D1 Hz ≤f 100 kHz Sis Sis OS s S Hz			•		
RMS value of the current, AC DC Measurement Synchronization Source Select voltage, current, or off In the case of Auto Update Rate, select the voltage or current from the equipped element. Line Filter Select voltage, current, or off In the case of Auto Update Rate, select the voltage or current from the equipped element. Line Filter Select voltage, current, or opwer from the instantaneous voltage, instantaneous current or instantaneous power that is sampled. Zero-level Compensation Removes the internal offset of the measure unit (After measurement range is changed) Measurement Parametersl Voltage Vms, Vm, Vdc, Vac Frequency IHz and VHz Current Imms, Idc, Iac Voltage Peak Vapk and Vpk Active Power P Current Peak Ipk and Vpk Active Power VA Active Power Peak Ipk and Vpk Reactive power VA Active Power Peak Ipk and Vpk Reactive power VA Mathematical Computation MATH WCrest Factor PF Mathematical Computation MATH Measurement Frequency Range Dis 20 Hz ≤ fs 100 kHz Vite Paak Vite Paak Measurement Frequency Range Dis 20 Hz ≤ fs 100 kHz S s S s	Display Mode Switching	Vrms (the true RMS val	ue of voltage and current)		
AC DC Measurement Synchronization Source Select voltage, current, or off In the case of Auto Update Rate, select the voltage or current from the equipped element. Line Filter Select OFF or ON (cutoff frequency at 500 Hz). Peak Measurement Measures the peak (max, min) value of voltage, current or power from the instantaneous voltage, instantaneous current or instantaneous power that is sampled. Zero-level Compensation Removes the internal offset of the measure unit (After measurement range is changed) Measurement Parametersl Voltage Vrms, Vrm, Vdc, Vac Frequency IHz and VHz Current Irms, Idc, Iac Voltage Peak V-pk and V-pk Active Power P Current Peak P+pk and P.pk Apparent Power VA Active Power Peak P+pk and P.pk Reactive power PF Mathematical Computation MATH Reactive power PF Mathematical Computation MATH Creet Pactor CFI, CFV Mathematical Computation MCR Paparent Power VA Active Power Pak M-pk and I-pk Measurement Item Specifications Voltage and current Mathematical Computation MATH Measurement Itequency Range 0.1 Hz ≤ fs 100		VOLTAGE MEAN (the re	ectified mean value calibrated to the RMS value of	the voltage and the true	
DC Measurement Synchronization Source Select OFF or ON (cutoff frequency at 500 H2). Pack Measurement Select OFF or ON (cutoff frequency at 500 H2). Pack Measurement Reasures the gale (max, min) value of voltage, current or power from the instantaneous voltage, instantaneous current or instantaneous power that is sampled. Zero-level Compensation Removes the internal offset of the measure unit (After measurement range is changed) It z and VHz Measurement Parameters! Voltage Vrms, Vnn, Vdc, Vac Frequency It z and VHz Measurement Parameters! Voltage ourrent Vnms, Ide, lac Voltage Peak V-phand V-pk Active Power P Current Peak I+pk and V-pk Apparent Power VA Active Power Peak P+pk and V-pk Apparent Power VAR Current Peak I+pk and V-pk Power Factor PF Mathematical Computation MATH MCR DEC DEC Dec Dec Enclevencer VHz Secrification Secrification Secrification Secrification Secrification Secrification Secrification Secrification Secrest Factor Secrification			t)		
Measurement Synchronization SourceSelect voltage, current, or off In the case of Auto Update Rate, select the voltage or current from the equipped element.Line FilterSelect OFF or ON (cutoff frequency at 500 Hz).Peak MeasurementMeasures the peak (max, min) value of voltage, current or power from the instantaneous voltage, instantaneous current or instantaneous power that is sampled.Zero-level CompensationRemoves the internal offset of the measure unit (After measurement range is changed)Measurement ParameterslVoltageVrms, Vmn, Vdc, VacFrequencyIHz and VHzCurrentIrms, ildc, lacVoltage PeakV+pk and V-pkCurrent bowerP AActive Power PeakP+pk and PpkApparent PowerVAActive Power PeakP+pk and PpkPower FactorPFMathematical ComputationMATHPower FactorCFI, CFVMaximum Current RatioMATHPhase AngleDEImage: Second					
Line Filter Select OFF or ON (cutoff frequency at 500 Hz). Peak Measurement Measures the peak (max, min) value of voltage, current or power from the instantaneous voltage, instantaneous current or instantaneous power that is sampled. Zero-level Compensation Removes the internal offset of the measure unit (After measurement range is changed) Measurement Parametersl Voltage Vms, Vmn, Vdc, Vac Frequency IHz and VHz Current Irms, vlnd, Vdc, Vac Frequency IHz and VHz V+pk and V-pk Active Power P Current Peak I+pk and I-pk Apparent Power VA Active Power Peak I+pk and I-pk Power Factor PF Mathematical Computation THDI and THDV Power Factor PF Mathematical Computation MATH Crest Factor CFI, CFV Mathematical Computation MATH Phase Angle DEG E E E Measurement Item Voltage and current Measurement Frequency Range 0.1 s 2.0 Hz ≤ f ≤ 100 kHz 2.5 s 0.1 Hz ≤ f ≤ 100 kHz 2.5 s 0.1 Hz ≤ f ≤ 100 kHz 2.5 s 0.5 Hz ≤ f ≤ 100 kHz 2.5 s 0.5 Hz ≤ f ≤ 100 kHz 2.5 s 0.5 Hz ≤ f ≤ 100 kHz	Measurement Synchronization Source		or off In the case of Auto I Indate Rate, select the	oltage or current from the equin	ned element
Peak Measurement Measures the peak (max, mi) value of voltage, current or power from the instantaneous voltage, instantaneous current or instantaneous power that is sampled. Zero-level Compensation Removes the internal offset of the measure unit (After measurement range is changed). Measurement Parametersl Voltage Vrms, Vmn, Vdc, Vac Frequency IHz and VHz Current Irms, Idc, Iac Voltage Peak V+pk and V-pk Active Power P Active Power Peak H-pk and I-pk Apparent Power VAR Active Power Peak H-pk and I-pk Neasurement Face DEG NATH MCR Pease Angle DEG NATH MCR Measurement Item Specifications Sectifications Sectifications Tess 20 Hz ≤ f 100 kHz Sectifications Sectifications Sectifications Sectifications 20 Hz ≤ f 100 kHz Ss 10 Hz ≤ f 5 100 kHz Ss 10 Hz ≤ f 5 100 kHz Os s 10 Hz ≤ f 5 100 kHz Ss 10 Hz ≤ f 5 100 kHz Ss Ss 10 Hz ≤ f 5 100 kHz Os s 0.5 Hz ≤ f 5 100 kHz Ss 0.5 Hz ≤ f 5 100 kHz Ss Ss Ss Ss	,			ionage of current from the equip	ped clement.
instantaneous current or instantaneous power that is sampled. Zero-level Compensation Removes the internal offset of the measure unit (After measurement range is changed) Measurement ParametersI Voltage Vms, Vmn, Vdc, Vac Frequency IHz and VHz Current Imms, Idc, Iac Voltage Peak V+pk and V-pk Active Power P Active Power Peak I+pk and I-pk Apparent Power VAR Active Power Peak P+pk and P.pk Reactive power VAR Active Power Peak P+pk and P.pk Power Factor PF Mathematical Computation MATH Power Factor CFI, CFV Maximum Current Ratio MATH Measurement Item Voltage and current McR NCR Measurement Frequency Range Data update interval Measurement Frequency Range S S 0.1 s 20 Hz S f S 100 kHz				instantaneous voltage	
Measurement ParametersIVoltage Current Active Power Apparent Power P Apparent Power Per Per Power Factor Per <th></th> <th>instantaneous current o</th> <th>r instantaneous power that is sampled.</th> <th></th> <th></th>		instantaneous current o	r instantaneous power that is sampled.		
	•			č ,	
Active PowerPCurrent PeakI+pk and 1-pkApparent PowerVAActive Power PeakP-pk and P-pkApparent PowerVARTotal Harmonic DistortionP-pk and P-pkReactive power FactorPFMathematical ComputationMATHCrest FactorCFI, CFVMaximum Current RatioMATHMessurement ItemSpecificationsVoltage and currentVoltage and currentVoltage and currentMeasurement Frequency RangeData update intervalMeasurement Frequency RangeNature Singer Sing	Measurement Parameters				
Apparent Power Reactive powerVAActive Power Peak Total Harmonic Distortion Mathematical Computation 					
Power Factor Crest Factor Phase AnglePF CFI, CFV DEGMathematical Computation MATH Maximum Current RatioMATH MCR FREQUENCY MEASUREMENT ItemSpecificationsMeasurement ItemVoltage and currentMeasurement Frequency Range 0.1 s20 Hz $\leq f \leq 100$ HHzData update interval 0.25 sMeasurement Frequency Range 0.1 s20 Hz $\leq f \leq 100$ HHz0.5 s5 Hz $\leq f \leq 100$ HHz5 s10 Hz $\leq f \leq 100$ HHz0.5 s0.5 Hz $\leq f \leq 100$ HHz5 s0.5 Hz $\leq f \leq 100$ HHz0.6 s0.5 Hz $\leq f \leq 100$ HHz5 s0.5 Hz $\leq f \leq 100$ HHz0.7 s0.0 Hz $\leq f \leq 100$ HHz5 s0.5 Hz $\leq f \leq 100$ HHz0.8 s0.5 Hz $\leq f \leq 100$ HHz5 s0.5 Hz $\leq f \leq 100$ HHz1 s0.2 Hz $\leq f \leq 100$ HHz5 s0.5 Hz $\leq f \leq 100$ HHz1 s0.2 Hz $\leq f \leq 100$ HHz5 s0.5 Hz $\leq f \leq 100$ HHz1 s0.2 Hz $\leq f \leq 100$ HHz5 s0.5 Hz $\leq f \leq 100$ HHz1 s0.2 Hz $\leq f \leq 100$ HHz5 s0.5 Hz $\leq f \leq 100$ HHz1 s0.2 Hz $\leq f \leq 100$ HHz5 s0.5 Hz $\leq f \leq 100$ HHz1 s0.2 Hz $\leq f \leq 100$ HHz1 Hz $\leq f \leq 100$ HHz1 Hz $\leq f \leq 100$ HHz1 s0.2 Hz $\leq f \leq 100$ HHz1 Hz $\leq f \leq 100$ HHz1 Hz $\leq f \leq 100$ HHz1 s0.2 Hz $\leq f \leq 100$ HHz1 Hz $\leq f \leq 100$ HHz1 Hz $\leq f \leq 100$ HHz1 s0.2 Hz $\leq f \leq 100$ HHz1 Hz $\leq f \leq 100$ HHz1 Hz $\leq f \leq 100$ HHz1 s0.3 Hz $\leq f \leq 100$ HHz1 Hz $\leq f \leq 100$ Hz1 Hz $\leq f \leq 100$				Active Power Peak	
$ \begin{array}{ c c c c } \hline Crest Factor & CFI, CFV & Maximum Current Ratio & MCR \\ \hline Phase Angle & DEG \\ \hline \hline \hline \\ \hline \hline \\ \hline \hline \\ \hline \\ \hline \\ \hline \\ \hline \\ $					
Phase Angle DEG FREQUENCY MEASUREMENT Specifications Measurement Item Voltage and current Measurement Frequency Range Data update interval Measurement Frequency Range 0.1 s 20 Hz ≤ f ≤ 100 kHz 0.25 s 10 Hz ≤ f ≤ 100 kHz 0.5 s 5 Hz ≤ f ≤ 100 kHz 1 s 2.0 Hz ≤ f ≤ 100 kHz 2 s 1.0 Hz ≤ f ≤ 100 kHz 2 s 0.5 Hz ≤ f ≤ 100 kHz 2 s 0.1 Hz ≤ f ≤ 100 kHz 2 s 0.1 Hz ≤ f ≤ 100 kHz 2 s 0.1 Hz ≤ f ≤ 100 kHz 2 s 0.1 Hz ≤ f ≤ 100 kHz 3 s 0.2 Hz ≤ f ≤ 100 kHz 3 s 0.2 Hz ≤ f ≤ 100 kHz 3 s 0.2 Hz ≤ f ≤ 100 kHz 3 s 0.2 Hz ≤ f ≤ 100 kHz 3 s 0.2 Hz ≤ f ≤ 100 kHz 3 s 0.2 Hz ≤ f ≤ 100 kHz 3 s 0.2 Hz ≤ f ≤ 100 kHz 4 uto (*) 0.1 Hz ≤ f ≤ 100 kHz (*) Limit of the measurement lower limit frequency by the Timeout setting Timeout lower limit frequency 3 s 0.5 Hz					
ItemSpecificationsMeasurement ItemVoltage and currentMeasurement Frequency RangeData update intervalMeasurement Frequency Range $0.1 s$ $20 Hz \le f \le 100 Hz$ $0.25 s$ $10 Hz \le f \le 100 Hz$ $0.5 s$ $5 Hz \le f \le 100 Hz$ $1 s$ $2.0 Hz \le f \le 100 Hz$ $2 s$ $1.0 Hz \le f \le 100 Hz$ $2 s$ $1.0 Hz \le f \le 100 Hz$ $2 s$ $1.0 Hz \le f \le 100 Hz$ $2 s$ $1.0 Hz \le f \le 100 Hz$ $2 s$ $0.1 Hz \le f \le 100 Hz$ $2 s$ $0.1 Hz \le f \le 100 Hz$ $2 s$ $0.1 Hz \le f \le 100 Hz$ $2 s$ $0.1 Hz \le f \le 100 Hz$ $1 s$ $0.2 Hz \le f \le 100 Hz$ $2 s$ $0.1 Hz \le f \le 100 Hz$ $2 s$ $0.1 Hz \le f \le 100 Hz$ $2 s$ $0.1 Hz \le f \le 100 Hz$ $1 term out$ $0 term ement lower limit frequency by the Timeout setting Timeout1 term out1 term out2 term out1 term out2 term out1 term out2 term out1 term out1 term out1 term out1 term out1 term out$,	can can can can and	
Measurement ItemVoltage and currentMeasurement Frequency RangeData update intervalMeasurement Frequency Range0.1 s $20 \text{ Hz} \le f \le 100 \text{ Hz}$ 0.25 s $10 \text{ Hz} \le f \le 100 \text{ Hz}$ 0.5 s $5 \text{ Hz} \le f \le 100 \text{ Hz}$ 1 s $2.0 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $1.0 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $1.0 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.5 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.5 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.5 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.5 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.5 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.5 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.5 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.5 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ 2 s 0.5 Hz	FREQUENCY MEASUREMENT				
Measurement Frequency RangeData update intervalMeasurement Frequency Range0.1 s20 Hz $\leq f \leq 100$ kHz0.25 s10 Hz $\leq f \leq 100$ kHz0.5 s5 Hz $\leq f \leq 100$ kHz1 s2.0 Hz $\leq f \leq 100$ kHz2 s1.0 Hz $\leq f \leq 100$ kHz5 s0.5 Hz $\leq f \leq 100$ kHz10 s0.2 Hz $\leq f \leq 100$ kHz20 s0.1 Hz $\leq f \leq 100$ kHz20 s0.1 Hz $\leq f \leq 100$ kHz10 s0.2 Hz $\leq f \leq 100$ kHz20 s0.1 Hz $\leq f \leq 100$ kHz10 s0.1 Hz $\leq f \leq 100$ kHz20 s0.1 Hz $\leq f \leq 100$ kHz10 s0.2 Hz $\leq f \leq 100$ kHz20 s0.1 Hz $\leq f \leq 100$ kHz1 s0.1 Hz $\leq f \leq 100$ kHz2 s0.1 Hz $\leq f \leq 100$ kHz2 s0.1 Hz $\leq f \leq 100$ kHz1 s0.1 Hz $\leq f \leq 100$ kHz2 s0.1 Hz $\leq f \leq 100$ kHz2 s0.1 Hz $\leq f \leq 100$ kHz2 s0.1 Hz $\leq f \leq 100$ kHz3 s0.1 Hz $\leq f \leq 100$ kHz4 uto (*)0.1 Hz $\leq f \leq 100$ kHz1 s2.0 Hz5 s0.5 Hz	Item	Specifications			
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	Measurement Item				
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	Measurement Frequency Range	· · ·			
$ \begin{array}{llllllllllllllllllllllllllllllllllll$					
$ \begin{array}{c cccc} 1 & s & 2.0 \ Hz \leq f \leq 100 \ Hz \\ 2 & s & 1.0 \ Hz \leq f \leq 100 \ Hz \\ 5 & s & 0.5 \ Hz \leq f \leq 100 \ Hz \\ 10 & s & 0.2 \ Hz \leq f \leq 100 \ Hz \\ 20 & s & 0.1 \ Hz \leq f \leq 100 \ Hz \\ 4uto (*) & 0.1 \ Hz \leq f \leq 100 \ Hz \\ 4uto (*) & 0.1 \ Hz \leq f \leq 100 \ Hz \\ (*) \ Limit of the measurement lower limit frequency by the Timeout setting Timeout & lower limit frequency \\ 1 & s & 2.0 \ Hz \\ 5 & s & 0.5 \ Hz \\ \end{array} $					
5 s $0.5 \text{ Hz} \le f \le 100 \text{ Hz}$ 10 s $0.2 \text{ Hz} \le f \le 100 \text{ Hz}$ 20 s $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ Auto (*) $0.1 \text{ Hz} \le f \le 100 \text{ Hz}$ (*) Limit of the measurement lower limit frequency by the Timeout settingTimeoutlower limit frequency1 s 2.0 Hz 5 s 0.5 Hz					
10 s $0.2 \text{ Hz} \le f \le 100 \text{ kHz}$ 20 s $0.1 \text{ Hz} \le f \le 100 \text{ kHz}$ Auto (*) $0.1 \text{ Hz} \le f \le 100 \text{ kHz}$ (*) Limit of the measurement lower limit frequency by the Timeout settingTimeoutlower limit frequency1 s 2.0 Hz 5 s 0.5 Hz					
20 s $0.1 \text{ Hz} \le f \le 100 \text{ kHz}$ Auto (*) $0.1 \text{ Hz} \le f \le 100 \text{ kHz}$ (*) Limit of the measurement lower limit frequency by the Timeout settingTimeoutlower limit frequency1 s 2.0 Hz 5 s 0.5 Hz					
Auto (*) $0.1 \text{ Hz} \le f \le 100 \text{ kHz}$ (*) Limit of the measurement lower limit frequency by the Timeout settingTimeoutlower limit frequency1 s2.0 Hz5 s0.5 Hz					
TimeoutIower limit frequency1 s2.0 Hz5 s0.5 Hz					
1 s 2.0 Hz 5 s 0.5 Hz				ng	
5 s 0.5 Hz			. ,		
		10 s	0.2 Hz		
20 s 0.1 Hz		20 s	0.1 Hz		

SPECIFICATIONS Measurement Range Frequency Filter Accuracy INTECRATION Item Mode Timer Accuracy Range Setting Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item Measured Method	Auto switching among six types: 100mHz, 1 Hz, 10 Hz, 100 Hz, 1 kHz, 10 kHz, and 100 kHz. Select OFF or ON (cut off frequency of 500 Hz) Requirements When the input signal level is 30% or more of the measurement range If the crest factor is set to 3. (60% or more if the crest factor is set to 6 or 6A)
Accuracy INTEGRATION Item Mode Timer Accuracy Range Setting Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item	Requirements When the input signal level is 30% or more of the measurement range If the crest factor is set to 3. (60% or more if the crest factor is set to 6 or 6A) • Frequency filter is ON when measuring voltage or current of 200 Hz or less. ± (0.06% of reading) Specifications Select manual integration mode, standard integration mode, or repetitive integration mode. Automatically stop integration by setting a timer. Selectable range: 0 hours 00 minutes 00 seconds to 9999 hours 59 minutes 59 seconds ± (Power accuracy (or current accuracy) + 0.1% of reading) (fixed range) Auto range or fixed range is available for Integration ±0.02% Start, stop and reset operations are available using an external remote signal. (option)
Accuracy INTEGRATION Item Mode Timer Accuracy Range Setting Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item	Requirements When the input signal level is 30% or more of the measurement range If the crest factor is set to 3. (60% or more if the crest factor is set to 6 or 6A) • Frequency filter is ON when measuring voltage or current of 200 Hz or less. ± (0.06% of reading) Specifications Select manual integration mode, standard integration mode, or repetitive integration mode. Automatically stop integration by setting a timer. Selectable range: 0 hours 00 minutes 00 seconds to 9999 hours 59 minutes 59 seconds ± (Power accuracy (or current accuracy) + 0.1% of reading) (fixed range) Auto range or fixed range is available for Integration ±0.02% Start, stop and reset operations are available using an external remote signal. (option)
Item Mode Timer Accuracy Range Setting Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item	the crest factor is set to 3. (60% or more if the crest factor is set to 6 or 6A) • Frequency filter is ON when measuring voltage or current of 200 Hz or less. ± (0.06% of reading) Specifications Select manual integration mode, standard integration mode, or repetitive integration mode. Automatically stop integration by setting a timer. Selectable range: 0 hours 00 minutes 00 seconds to 9999 hours 59 minutes 59 seconds ±(Power accuracy (or current accuracy) + 0.1% of reading) (fixed range) Auto range or fixed range is available for Integration ±0.02% Start, stop and reset operations are available using an external remote signal. (option)
Item Mode Timer Accuracy Range Setting Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item	Frequency filter is ON when measuring voltage or current of 200 Hz or less. ± (0.06% of reading) Specifications Select manual integration mode, standard integration mode, or repetitive integration mode. Automatically stop integration by setting a timer. Selectable range: 0 hours 00 minutes 00 seconds to 9999 hours 59 minutes 59 seconds ±(Power accuracy (or current accuracy) + 0.1% of reading) (fixed range) Auto range or fixed range is available for Integration ±0.02% Start, stop and reset operations are available using an external remote signal. (option) Specifications
Item Mode Timer Accuracy Range Setting Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item	± (0.06% of reading) Specifications Select manual integration mode, standard integration mode, or repetitive integration mode. Automatically stop integration by setting a timer. Selectable range: 0 hours 00 minutes 00 seconds to 9999 hours 59 minutes 59 seconds ± (Power accuracy (or current accuracy) + 0.1% of reading) (fixed range) Auto range or fixed range is available for Integration ± 0.02% Start, stop and reset operations are available using an external remote signal. (option) Specifications
Item Mode Timer Accuracy Range Setting Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item	Select manual integration mode, standard integration mode, or repetitive integration mode. Automatically stop integration by setting a timer. Selectable range: 0 hours 00 minutes 00 seconds to 9999 hours 59 minutes 59 seconds ±(Power accuracy (or current accuracy) + 0.1% of reading) (fixed range) Auto range or fixed range is available for Integration ±0.02% Start, stop and reset operations are available using an external remote signal. (option)
Mode Timer Accuracy Range Setting Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item	Select manual integration mode, standard integration mode, or repetitive integration mode. Automatically stop integration by setting a timer. Selectable range: 0 hours 00 minutes 00 seconds to 9999 hours 59 minutes 59 seconds ±(Power accuracy (or current accuracy) + 0.1% of reading) (fixed range) Auto range or fixed range is available for Integration ±0.02% Start, stop and reset operations are available using an external remote signal. (option)
Timer Accuracy Range Setting Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item	Automatically stop integration by setting a timer. Selectable range: 0 hours 00 minutes 00 seconds to 9999 hours 59 minutes 59 seconds ±(Power accuracy (or current accuracy) + 0.1% of reading) (fixed range) Auto range or fixed range is available for Integration ±0.02% Start, stop and reset operations are available using an external remote signal. (option)
Accuracy Range Setting Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item	Selectable range: 0 hours 00 minutes 00 seconds to 9999 hours 59 minutes 59 seconds ±(Power accuracy (or current accuracy) + 0.1% of reading) (fixed range) Auto range or fixed range is available for Integration ±0.02% Start, stop and reset operations are available using an external remote signal. (option) Specifications
Range Setting Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item	±(Power accuracy (or current accuracy) + 0.1% of reading) (fixed range) Auto range or fixed range is available for Integration ±0.02% Start, stop and reset operations are available using an external remote signal. (option) Specifications
Range Setting Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item	Auto range or fixed range is available for Integration ±0.02% Start, stop and reset operations are available using an external remote signal. (option) Specifications
Timer Accuracy Remote Control HARMONIC MEASUREMENT Item Measured Item	Start, stop and reset operations are available using an external remote signal. (option) Specifications
HARMONIC MEASUREMENT Item Measured Item	Specifications
Item Measured Item	
Measured Item	
	Voltage, Current, Power
	Zero-cross simultaneous calculation method
Frequency Range	10 Hz to 1.2 kHz.
FFT Data Length	4096 (Auto switch when both 50Hz/60Hz and update rate must be greater than or equal to 0.5s)
Sample rate, window width, and upper limit of Analysis	Fundamental FrequencySample rate Window Width upper limit of Analysis orders 45 Hz to 55 Hz f×512 10 50
orders*	43 Hz to 55 Hz 1 × 512 10 30 54 Hz to 66 Hz f × 512 12 50
FFT Data Length	1024
Sample rate, window width, and upper limit of Analysis	Fundamental Frequency Sample rate Window Width upper limit of Analysis orders 10 Hz to 67 Hz f × 1024 1 50
orders*	67 Hz to 150 Hz f×512 2 32
	150 Hz to 300 Hz f × 256 4 16
	300 Hz to 600 Hz f × 128 8 8 600 Hz to 1200 Hz f × 64 16 4
Accuracy	Frequency Voltage Current Power
	$10 \text{ Hz} \le f < 45 \text{ Hz}$ 0.15% of reading 0.15% of reading 0.35% of reading 0.35% of reading
	$\begin{array}{c} + 0.35\% \text{ of range} \\ 45 \text{ Hz} \leq f < 440 \text{ Hz} \end{array} \begin{array}{c} + 0.35\% \text{ of range} \\ 0.15\% \text{ of reading} \\ 0.15\% \text{ of reading} \end{array} \begin{array}{c} + 0.50\% \text{ of range} \\ 0.25\% \text{ of reading} \\ 0.25\% \text{ of reading} \end{array}$
	+ 0.35% of range + 0.35% of range + 0.50% of range
	440 Hz \leq f < 1.2kHz 0.20% of reading 0.20% of reading 0.40% of reading 0.20% of reading
	+ 0.35% of range + 0.35% of range + 0.50% of range
* 50Hz/60Hz Compliant IEC61000-4-7	7 (update rate must be > 0.5s) n which FFT data length is divided into 2 types: 1024 and 4096.
	nes in accord with the Frequency and Update Rate of measured signal.
D/A OUTPUT (OPTIONS)	
Item	Specifications
Output Voltage	±5 V FS (approach ±7.5 V maximum) against each rated value.
Number Of Output Channels Output Items	12 Set for each channel: V, I, P, VA, VAR, PF, DEG, VHZ, IHZ, Vpk, Ipk, WP, WP±, q, q±, Off
Accuracy	\pm (accuracy of each measurement item + 0.2% of FS) (FS = 5 V)
D/A Conversion Resolution	16 bits
Minimum Load	100 kΩ
Update Interval	Same as the data update interval. In the case of Auto Update Rate, update interval is equal to signal interval. More than 100ms.
Temperature Coefficient	±0.05%/°C of FS
REMOTE CONTROL INPUT/OUTPUT	,
Item	Specifications
Remote Control Input Signal	EXT HOLD, EXT TRIG, EXT START, EXT STOP, EXT RESET
Remote Control Output Signal	INTEG BUSY
I/O Level I/O Logic Format	TTL Negative logic, Falling edge
	re originated from the measured values including voltage, current and active power which go through computation process. ordingly, the value acquired from other instruments, which employ different methods, may differ from that acquired from
GPM-8320/8330 unit.	
 * "Zero" will be shown for S or Q and "" 1% when crest factor is set 6) 	" will be displayed for λ and Φ when either current or voltage is less than 0.5% of the rated range (less than or equivalent to
GENERAL	
	The below are the basic conditions required to operate the CDM \$220/\$220 within specifications:
	The below are the basic conditions required to operate the GPM-8320/8330 within specifications:
∠ ! Note	 1-year Calibration: Yearly Operating Environment: 18~28 °C (64.4~82.4 °F) The power supply cable must be grounded to ensure accuracy. Input voltage and current must be standard sine wave.
	 Humidity: <80%RH, The power factor must be 1.
	 Accuracy: ± (% of reading + % of range) The crest factor must be 3.
	• The specifications apply when it warmed up for at least • The common-mode voltage must be zero.
	30 minutes and operates in the slow rate.

SPECIFICATIONS	
Specification Condition	Temperature: 23°C±5°C; Humidity: <80%RH(non-condensing)
Operation Condition	Temperature 0°C ~ 40°C, • 30 ~ 40°C, Relative Humidity < 70%RH (non-condensing) • >40°C, Relative Humidity < 50%RH (non-condensing) Indoor use only Altitude: < 2000 meters Pollution degree 2
Storage Condition	Temperature –40°C ~ 70°C ; Humidity: < 90%RH (non-condensing)
Power Source	AC 100-240V, 50–60Hz ; Consumption Max. 35VA
Dimensions	220(W) x 132(H) x 402.5(D)mm(w/t bumpers)
Weight	Approx. 3.85kg

ORDERING INFORMATION

GPM-002

GTL-209

 GPM-8320
 Digital Power Meter (RS-232C/USB device & Host/LAN)

 GPM-8320
 Digital Power Meter (RS-232C/USB device & Host/LAN and opt. GPIB+DA12)

 (with GPM-8330)
 Digital Power Meter (RS-232C/USB device & Host/LAN)

 GPM-8330
 Digital Power Meter (RS-232C/USB device & Host/LAN and opt. GPIB+DA12)

 (with GPM-8310)
 Digital Power Meter (RS-232C/USB device & Host/LAN and opt. GPIB+DA12)

 Safety Instruction Sheet x 1, Power cord x 1, Test lead GTL-209 x 2, Test lead GTL-212A x 2 (for GPM-8320), Test lead GTL-209 x 3, Test lead GTL-212A x 3 (for GPM-8330), CD x 1 (including complete user manual and USB driver), DA12 cable GTL-214 (available for GPM-8320/8330 with GPM-DA12 only), GPM-002 Terminal Cover

 Image:
 Image:
 Image:

 Image:
 Image:</td

GTL-212A

Specificatio	ons subject to change without notice. PM-83208330CD1BH
OPTION	
GPM-DA1	2 GPIB+DA12 Interface (including cable, GTL-214)
Note : The o	ption is 2-in-1 interface and must be installed in factory.
OPTION	ACCESSORIES
GTL-209	Test Lead, Banana to Bare-wire, Approx. 1000mm
GTL-212A	Test Lead, O-Type to Bare-wire, Approx. 1000mm
GTL-214	DA4 Cable, Approx. 1000mm
GTL-232	RS-232C cable, 9-pin Female to 9-pin, null modem
	for computer, Approx. 2000mm
GTL-246	USB Cable, A-B type, Approx. 1200mm
GTL-258	GPIB Cable, 25-pin Micro-D Connector,
	Approx. 1900mm
GRA-452	Rack Mount Kit, 19" 3U size
1	

Global Headquarters **GOOD WILL INSTRUMENT CO., LTD.** No.7-1, Jhongsing Road, Tucheng Dist., New Taipei City 236, Taiwan **T** +886-2-2268-0389 **F** +886-2-2268-0639

T +886-2-2268-0389 F +886-2-2268-0639 E-mail: marketing@goodwill.com.tw

China Subsidiary

GOOD WILL INSTRUMENT (SUZHOU) CO., LTD. No. 521, Zhujiang Road, Snd, Suzhou Jiangsu 215011 China T +86-512-6661-7177 F +86-512-6661-7277

Malaysia Subsidiary

GOOD WILL INSTRUMENT (SEA) SDN. BHD.

No. 1-3-18, Elit Avenue, Jalan Mayang Pasir 3, 11950 Bayan Baru, Penang, Malaysia T +604-6111122 F +604-6115225

Europe Subsidiary

GOOD WILL INSTRUMENT EURO B.V.

De Run 5427A, 5504DG Veldhoven, THE NETHERLANDS T +31(0)40-2557790 F +31(0)40-2541194 U.S.A. Subsidiary
INSTEK AMERICA CORP.

GTL-214

5198 Brooks Street Montclair, CA 91763, U.S.A. T +1-909-399-3535 F +1-909-399-0819 Japan Subsidiary

TEXIO TECHNOLOGY CORPORATION.

7F Towa Fudosan Shin Yokohama Bldg., 2-18-13 Shin Yokohama, Kohoku-ku, Yokohama, Kanagawa, 222 0022 Japan

222-0033 Japan T +81-45-620-2305 F +81-45-534-7181 Korea Subsidiary

GOOD WILL INSTRUMENT KOREA CO., LTD.

Room No.503, Gyeonginro 775 (Mullae-Dong 3Ga, Ace Hightech-City B/D 1Dong), Yeongduengpo-Gu, Seoul 150093, Korea. T +82-2-3439-2205 F +82-2-3439-2207

India Subsidiary GW INSTEK INDIA LLP.

Gw INSTEX INDIA LLP. No.2707/B&C, 1st Floor UNNATHI Building, E-Block, Sahakara Nagar, Bengaluru-560 092. India T +91-80-6811-0600 F +91-80-6811-0626



Simply Reliable

Facebook



Website

