GOS-620 20MHz Dual Trace Oscilloscope

820S-62000MC

CONTENTS

1. GENERAL	1
1.1 Description	1
1.2 Features	
2. TECHNICAL SPECIFICATIONS.	2
3. PRECAUTIONS BEFORE OPERATING THE OSCILLOSCOPE	5
3.1 Unpacking the Oscilloscope	
3.2 Checking the Line Voltage	
3.3 Environment	6
3.4 Equipment Installation, and Operation	6
3.5 CRT Intensity	
3.6 Withstanding Voltages of Input Terminals	6
4. OPERATION METHOD	8
4.1 Introduction of Front Panel	9
4.2 Introduction of Rear Panel	12
4.3 Basic Operation-Single channel Operation	
4.4 Dual-Channel Operation	
4.5 ADD Operation	15
4.6 Triggering	
4.7 TIME/DIV control.	
4.8 Sweep Magnification	
4.9 X-Y Operation	
4.10 Calibration of Probe	
4.11 DC BAL Adjustments	
5. MAINTENANCE	21
5.1 Fuse replacement	21
5.2 Line Voltage Conversion	
5.3 Cleaning	
6.BLOCK DIAGRAM	22

— ii —

SAFETY TERMS AND SYMBOLS

These terms may appear in this manual or on the product:



WARNING. Warning statements identify condition or practices that could result in injury or loss of life.



CAUTION. Caution statements identify conditions or practices that could result in damage to this product or other property.

The following symbols may appear in this manual or on the product:





DANGER **High Voltage**



Protective Conductor Terminal



Earth(ground) Terminal

FOR UNITED KINGDOM ONLY

NOTE This lead/appliance must only be wired by competent persons WARNING

THIS APPLIANCE MUST BE EARTHED IMPORTANT The wires in this lead are coloured in accordance with

the following code: Green/ Yellow: Earth Blue: Neutral

Brown: Live(Phase)



As the colours of the wires in main leads may not correspond with the colours marking identified in your plug/appliance, proceed as follows:

The wire which is coloured Green & Yellow must be connected to the Earth terminal marked with

the letter E or by the earth symbol \bigoplus or coloured Green or Green & Yellow. The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured Blue or Black.

The wire which is coloured Brown must be connected to the terminal marked with the letter L or P or coloured Brown or Red.

If in doubt, consult the instructions provided with the equipment or contact the supplier.

This cable/appliance should be protected by a suitably rated and approved HBC mains fuse : refer to the rating information on the equipment and/or user instructions for details. As a guide, cable of 0.75mm² should be protected by a 3A or 5A fuse. Larger conductors would normally require 13A types, depending on the connection method used.

Any moulded mains connector that requires removal/replacement must be destroyed by removal of any fuse & fuse carrier and disposed of immediately, as a plug with bared wires is hazardous if a engaged in live socket. Any re-wiring must be carried out in accordance with the information detailed on this label.

EC Declaration of Conformity

We

GOOD WILL INSTRUMENT CO., LTD.

(1) No.7-1, Jhongsing Rd, Tucheng City, Taipei County236. Taiwan.

(2) NO. 69 Lushan Road, Suzhou New District Jiangsu, China.

declare that the below mentioned product

GOS-620

are herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Law of Member States relating to Electromagnetic Compatibility (89/336/EEC,92/31/EEC,93/68/EEC) and Low Voltage Equipment Directive (73/23/EEC).

For the evaluation regarding the Electromagnetic Compatibility and Low Voltage Equipment Directive, the following standards were applied:

	EN 55022 class B	(1994)	Electrostatic Discharge	IEC 1000-4-2	(1995)
Radiated Emission	EN 55011 class B	(1991)	Radiated Immunity	IEC 1000-4-3	(1995
Current Harmonics	EN 61000-3-2	(1995)	Electrical Fast Transients	IEC 1000-4-4	(1995)
Voltage Fluctuations	EN 61000-3-3	(1995)	Surge Immunity	IEC 1000-4-5	(1995)
			Conducted Susceptibility	EN 61000-4-6	(1996)
			Power Frequency Magnetic field	EN 61000-4-8	(1993)
			Voltage Dip/Interruption	EN 61000-4-11	(1994)

1. GENERAL

1.1 Description

The GOS-620 oscilloscope is a portable-type, dual-channel oscilloscope with a bandwidth of DC to 20MHz, and maximum sensitivity of 1 mV/DIV. The time base provides a maximum sweep time of 0.2uS/DIV. When magnified by 10, the sweep speed is 100nS/DIV. The oscilloscope employs a 6-inch rectangular type cathode-ray tube with red internal graticule. These oscilloscope is sturdy, easy to operate and exhibits high operational reliability.

1.2 Features

1) High intensity CRT with high acceleration voltage:

The CRT is a high beam transmission, high intensity type with a high acceleration voltage of 2KV. It displays clear readable traces even at high sweep speeds.

2) Wide bandwidth and sensitivity:

In addition to wide bandwidth, DC-20MHz (-3dB), this instrument provide high sensitivity of 5mV/DIV (1mV/DIV at x5 MAG). A 20MHz frequency is obtained with improved triggered synchronization.

3) Alternate triggering:

Even an observation of two waveforms of different frequencies, the waveform of the each channel is stably triggered.

4) TV sync triggering:

The oscilloscope has a sync separator circuit for triggering of TV-V and TV-H signals.

5) CH1 Output:

Terminated 50 output of channel 1 signal available on rear panel for driving frequency counter or other instruments.

6) Z-Axis Input:

Intensity modulation capability permits time or frequency markers to be added. Trace blank with positive signal, TTL compatible.

7) X-Y operation:

Set the switch to X-Y. Then the instrument works as an X-Y oscilloscope. CH1 can be applied as horizontal deflection(X-axis) while CH2 provide vertical deflection (Y-axis).

TECHNICAL SPECIFICATIONS

SPECIFICATIO	MODEL	GOS-620 20MHz OSCILLOSCOPE			
Sensitivity					
		$5 \text{mV} \sim 5 \text{V/DIV}$, 10 steps in 1-2-5 sequence			
	Sensitivity accuracy	$\leq 3\%$ (x 5 MAG : $\leq 5\%$)			
	Vernier vertical sensitivity	To 1/2.5 or less of panel-indicated value.			
	Frequency bandwidth	$DC \sim 20 MHz$ (x 5MAG: $DC \sim 7 MHz$)			
		AC coupling: Low limit frequency 10Hz. (With reference to 100kHz,8DIV. Frequency response with -3dB.)			
	Rise time	Approx. 17.5 nS (x5 MAG : Approx. 50 nS)			
	Input impedance	Approx. 1M ohm // Approx. 25pF			
	Square wave characteristics	$Overshoot : \le 5\% (At 10mV/DIV range)$			
		Other distortions and other ranges : 5% added to the above value.			
	DC balance shift	Adjustable on panel.			
	Linearity	$<\pm 0.1$ DIV of amplitude change when waveform of 2 DIV at graticule center is moved vertically.			
VERTICAL	Vertical modes	CH1 : CH1 single channel.			
AXIS		CH2 : CH2 single channel.			
		DUAL : CH1 and CH2 are displayed . ALT or CHOP selectable at any sweep rate .			
		ADD : CH1 + CH2 algebraic addition			
	Chopping repetition frequency	Approx. 250kHz			
	Input coupling	AC, GND, DC			
	Maximum input voltage	300Vpeak (AC: frequency 1kHz or lower).			
		When set probe switch at 1: 1, the maximum effective readout is 40Vpp (14Vrms at sine wave),			
		or set probe switch at 10: 1, the maximum effective readout is 400 Vpp (14 Vins at sine wave).			
	Common mode rejection ratio	50:1 or better at 50kHz sinusoidal wave. (When sensitivities of CH1 and CH2 are set equally)			
	Isolation between channels	> 1000:1 at 50kHz			
	(At 5mV/DIV range)	> 30:1 at 20MHz			
	CH1 signal output	At least 20 mV/div into a 50 ohm termination. Bandwidth is 50Hz to at least 5MHz.			
	CH2 INV BAL.	Balanced point variation : ≤ 1 div (Reference at center graticule.)			

MODEL		GOS-620 20MHz OSCILLOSOPE	
SPECIFICATIO	NS Triggering source	CH1, CH2, LINE, EXT (CH1 and CH2 can be selected only when the vertical mode is DUAL or ADD.	
		In ALT mode, if the TRIG. ALT switch is pushed in, it can be use for alternate triggering of two different source.	
	Coupling	AC: 20Hz to full bandwidth	
	Slope	+/.	
	Sensitivity	20Hz ~ 2MHz : 0.5 div , TRIG-ALT:2 div , EXT : 200mV	
		$2 \sim 20$ MHz : 1.5 div , TRIG-ALT:3 div , EXT : 800 mV	
		TV : Sync pulse more than 1 div (EXT: 1V)	
TRIGGERING	Triggering modes	AUTO : Sweeps run in the free mode when no triggering input signal is applied.	
INICOLINIC		(Applicable for repetitive signals of frequency 25Hz or over.)	
		NORM: When no triggering signal is applied, the trace is in the ready state and not displayed.	
		TV-V This setting is used when observing the entire vertical picture of television signal.	
		TV-H : This setting is used when observing the entire horizontal picture of television signal.	
	Dave in the set	(Both TV-V and TV-H synchronize only when the synchronizing signal is negative)	
	EXT triggering signal input	Approx. : 1M ohm // approx. 25pF	
	Input impedance Max. input voltage	300V (DC+AC peak), AC: Frequency not higher than 1kHz	
	Sweep time	0.2μ Sec ~ 0.5 Sec/DIV, 20 steps in 1-2-5 sequence	
	Sweep time accuracy	±3%	
HORIZIONAL	Vernier sweep time control	$\leq 1/2.5$ of panel-indicated value	
	Sweep magnification	10 times	
AXIS	x10MAG sweep time accuracy	\pm 5%, (20nSec ~ 50nSec are uncalibrated)	
	Linearity	\pm 3%, x10MAG: \pm 5% (20ns and 50ns are uncalibrated)	
	Position shift caused by x10MAG	Within 2 div. at CRT screen center	
	Sensitivity	Same as vertical axis.(X-axis:CH1 input signal; Y-axis:CH2 input signal.)	
X-Y MODE	Frequency bandwidth	DC to at least 500kHz	
	X-Y phase difference	\leq 3° at DC ~ 50kHz	

۰.

 $\hat{}$

SPECIFICATIO	MODEL	GOS-620 20MHz OSCILLOSCOPE	
	Sensitivity	5 Vp-p (Positive -going signal decreases intensity)	
	Frequency bandwidth	$DC \sim 2MHz$	
Z AXIS	Input resistance	Approx. 47K ohm	
	Maximum input voltage	30 V (DC+AC peak, AC frequency≤ 1kHz)	
	Waveform	Positive-going square wave	
	Frequency	Approx. 1 kHz	
CALIBRATION	Duty ratio	Within 48:52	
VOLTAGE	Output voltage	2 Vp-p ±2%	
	Output impedance	Approx. 1 K ohm.	
1	Туре	6-inch rectangular type, internal graticule.	
	Phosphor	P 31	
CRT	Acceleration voltage	Approx. 2 kV	
	Effective screen size	8 x 10 DIV (1 DIV = 10mm(0.39in))	
	Graticule	Internal	
	Trace rotation	Provided	

Line Power Requirements

Voltage: AC 115V, 230V±15% selectableFrequency: 50Hz or 60HzPower consumption: Approx. 40VA, 35W(max.)

Mechanical Specifications

Dimensions : 310 W x 150 H x 455 D (mm) Weight : Approx.8Kg (17.6 lbs.)

Operating Environment

Indoor use Altitude up to 2000 m Ambient temperature : To satisfy specifications :10° to 35 °C (50° to 95° F) Maximum operating ranges: 0° to 40 °C (32 °to 104° F) Relative humidity:85% RH(max.) non condensing Installation Category II Pollution degree 2

Storage Temperature & Humidity

-10° to 70 °C,70%RH(maximum)

Accessories

Power cord1
Instruction manual1
Probes 2

_ 4 _

3. PRECAUTIONS BEFORE OPERATING THE OSCILLOSCOPE

3.1 Unpacking the Oscilloscope

The oscilloscope is shipped from the factory after being fully inspected and tested. Upon receiving the instrument, immediately unpack and inspect it for any damages that might have been sustained during transportation. If any sign of damage is found, immediately notify the bearer and/or the dealer.

3.2 Checking the Line Voltage

These oscilloscopes will operate on any one of the line voltage shown in the table below, by inserting the line voltage selector plug in the corresponding position on the rear panel. Before connecting the power plug to an AC line outlet, make sure the voltage selector is set to the correct position corresponding to the line voltage. Note the oscilloscope may be damaged if it is connected to the wrong AC line voltage.

5



WARNING. To avoid electrical shock the power cord protective grounding conductor must be connected to ground.

When line voltages are changed, replace the required fuses shown below.

Line voltage	Range	Fuse		
		T 0.63A		
AC 115V	97~132V	250V		
		T 0.315A		
AC 230V	195~250V	250V		



WARNING. To avoid personal injury, disconnect the power cord before removing the fuse holder.

3.3 Environment

The normal ambient temperature range of this instrument is 0° to 40°C (32° to 104°F). Operation of the instrument above this temperature range may cause damage to the circuits.

Do not use the instrument in a place where strong magnetic or electric field exists. Such fields may disturb the measurement.

3.4 Equipment Installation, and Operation

Ensure there is proper ventilation for the hole vents in the oscilloscope case.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

3.5 CRT Intensity

To prevent permanent damage to the CRT phosphor, do not make the CRT trace excessively bright or leave the spot stationary for an unreasonably long time.

3.6 Withstanding Voltages of Input Terminals

The withstanding voltages of the instrument input terminals and probe input terminals are as shown in the following table. Do not apply voltages higher than these limits. When set probe switch at 1:1, the maximum effective readout is 40Vpp (14Vrms at sine wave). When set probe switch at 10:1, the maximum effective readout is 400Vpp(140Vrms at sine wave).

Input terminal	Maximum input voltage		
CH1, CH2, inputs	300Vpeak		
EXT TRIG IN input	300Vpeak		
Probe inputs	600Vpeak		
Z AXIS input	30Vpeak		

A CAUTION. To avoid instrument damage, do not exceed maximum input voltages. Maximum input voltages must have frequencies less than 1 kHz.

If an AC voltage which is superimposed on a DC voltage is applied, the maximum peak value of CH1 and CH2 input voltages must not exceed + or - 300V. So for AC voltages with a mean value of zero volt the maximum peak to peak value is 600Vpp

Figure 4-1

MODE GOS-620



\$

۰

1

Figure 4-2

model GOS-620



4. OPERATION METHOD

4.1 Introduction of Front Panel

CRT:

Filter for ease of waveform viewing.

Vertical Axis:

CH 1 (X) input(8)
Vertical input terminal of CH 1. When in X-Y operation, X-axis input terminal.
CH 2 (Y) input(20)
Vertical input terminal of CH 2. When in X-Y operation, Y-axis input terminal.
AC-GND-DC(10)(18)
Switch for selecting connection mode between input signal and vertical amplifier.
AC : AC coupling
GND : Vertical amplifier input is grounded and input terminals are disconnected.
DC : DC coupling
VOLTS/DIV(7)(22)
Select the vertical axis sensitivity, from 5mV/DIV to 5V/DIV in 10 ranges.

VARIABLE.....(9)(21)

Fine adjustment of sensitivity, with a factor of $\geq 1/2.5$ of the indicated value. When in the CAL position, sensitivity is calibrated to indicated value. When this knob is pulled out(x5 MAG state), the amplifier sensitivity is multiplied by 5.

CH1 & CH2 DC BAL.(13)(17)

These are used for the attenuator balance adjustment. See page 20 DC BAL adjustments for the details.

▲ ▼ POSITION.....(11)(19)

Vertical positioning control of trace or spot.

VERT MODE.....(14)

Select operation modes of CH 1 and CH 2 amplifiers.

- CH 1 : The oscilloscope operates as a single-channel instrument with CH 1 alone.
- CH 2 : The oscilloscope operates as a single-channel instruments with CH 2 alone.
- DUAL : The oscilloscope operates as a dual-channel instrument both CH 1 and CH 2.
- ADD : The oscilloscope displays the algebraic sum (CH 1 + CH 2) or difference (CH 1 CH 2) of the two signals. The pushed in state of CH 2 INV(16) button is for the difference (CH 1 - CH 2).

ALT/CHOP.....(12)

When this switch is released in the dual-trace mode, the channel 1 and channel 2 inputs are alternately displayed (normally used at faster sweep speeds).

When this switch is engaged in the dual-trace mode, the channel 1 and channel 2 inputs are chopped and displayed simultaneously (normally used at slower sweep speeds).

CH2 INV.....(16)

Inverts the CH2 input signal when the CH2 INV switch mode is pushed in The channel 2 input signal in ADD mode and the channel 2 trigger signal pickoff are also inverted.

Triggering:

EXT TRIG IN input terminal......(24)

Input terminal is used for external triggering signal. To use this terminal, set SOURCE switch (23) to the EXT position.

SOURCE.....(23)

Select the internal triggering source signal, and the EXT TRIG IN input signal.

- CH 1 : When the VERT MODE switch(14) is set in the DUAL or ADD state, select CH 1 for the internal triggering source signal.
- CH 2 : When the VERT MODE switch(14) is set in the DUAL or ADD state, select CH 2 for the internal triggering source signal.
- TRIG.ALT(27) : When the VERT MODE switch(14) is set in the DUAL or ADD state, and the SOURCE switch(23) is selected at CH 1 or CH 2, with the engagement of the TRIG.ALT switch(27), it will alternately select CH 1 & CH 2 for the internal triggering source signal.
- LINE : To select the AC power line frequency signal as the triggering signal.
- EXT : The external signal applied through EXT TRIG IN input terminal(24) is used for the external triggering source signal.

SLOPE......(26)

Select the triggering slope.

- "+" : Triggering occurs when the triggering signal crosses the triggering level in positive-going direction.
- "-" Triggering occurs when the triggering signal crosses the triggering level in negative-going direction.

To display a synchronized stationary waveform and set a start point for the waveform.

Toward "+" The triggering level moves upward on the display waveform.

Toward "-" : The triggering level moves downward on the display waveform.

TRIGGER MODE....(25)

Select the desired trigger mode.

- AUTO : When no triggering signal is applied or when triggering signal frequency is less than 25 Hz, sweep runs in the free run mode.
- NORM : When no triggering signal is applied, sweep is in a ready state and the trace is blanked out. Used primarily for observation of signal \leq 25 Hz.
- TV-V : This setting is used when observing the entire vertical picture of television signal.
- TV-H : This setting is used when observing the entire horizontal picture of television signal.

(Both TV-V and TV-H synchronize only when the synchronizing signal is negative.)

Time Base

TIME/DIV.....(29)

Sweep time ranges are available in 20 steps from 0.2 uS/div to 0.5 S/div.

X-Y : This position is used when using the instrument as an X-Y oscilloscope.

SWP.VAR.....(30)

Vernier control of sweep time. This control works as CAL and the sweep time is calibrated to the value indicated by TIME/DIV. TIME/DIV of sweep can be varied continuously when shaft is out of CAL position. Then the control is rotated in the direction of arrow to the full, the CAL state is produced and the sweep time is calibrated to the value indicated by TIME/DIV. Counterclockwise rotation to the full delays the sweep by 2.5 time or more.

• • POSITION.....(32)

Horizontal positioning control of the trace or spot.

x 10 MAG.....(31)

When the button is pushed in, a magnification of 10 occurs.

Others

CAL.....(1)

This terminal delivers the calibration voltage of 2 Vp-p, 1kHz, positive square wave.

GND.....(15)

Ground terminal of oscilloscope mainframe.

4.2 Introduction of Rear Panel

Z AXIS INPUT.....(34)

Input terminal for external intensity modulation signal.

CH 1 SIGNAL OUTPUT (35)

Delivers the CH 1 signal with a voltage of approximately 20mV per 1 DIV into a 50-ohm termination. Suitable for frequency counting, etc.

AC POWER Input Circuit

AC Power input connector.....(36)

AC Power input socket. Connect the AC power cord(supplied) to this connector.

FUSE & line voltage selector.....(37)

Fuse rating is shown in Page 5. Line voltage selector to select power sources.

Studs......(38)

Studs for laying the oscilloscope on its back to operate it in the upward posture. Also used to take up the power cord.

4.3 Basic Operation---Single-channel Operation

Before connecting the power cord to an AC line outlet, make sure that the AC line voltage input switch on the rear panel of the instrument is correctly set for the AC line voltage. After ensuring the voltage setting, set the switches and controls of the instrument as shown below:

Item	No	Setting	Item	No	Setting
POWER INTEN FOCUS VERT MODE ALT/CHOP CH 2 INV	(6) (2) (3) (14) (12) (16) (11)(19) (7)(22) (9)(21) (10)(18) (23)	Disengage position(OFF) Mid-position CH 1 Released(ALT) Released Mid-position 0.5V/DIV CAL(clockwise position) GND CH 1	SLOPE TRIG. ALT TRIGGER MODE TIME/DIV SWP. VER ↓ ▶ POSITION x10 MAG	(26) (27) (25) (29) (30) (32) (31)	+ Released AUTO 0.5mSec/DIV CAL position Mid-position Released

After setting the switches and controls as mentioned, connect the power cord to the AC line outlet, and then, continue as follows:

- 1) Engage the POWER switch and make sure that the power LED is turned on. In about 20 seconds, a trace will appear on the CRT screen. If no trace appears in about 60 seconds, counter check the switch and control setting.
- 2) Adjust the trace to an appropriate brightness and image with the INTEN control and FOCUS control respectively.
- 3) Align the trace with the horizontal centre line of the graticule by adjusting the CH 1 POSITION control and TRACE ROTATION control(adjustable by screwdriver).
- 4) Connect the probe to the CH 1 INPUT terminal and apply the 2Vp-p CALIBRATOR signal to the probe tip.
- 5) Set the AC-GND-DC switch to the AC state. A waveform as shown in the figure 4-3 will be displayed on the CRT screen
- 6) Adjust the FOCUS control so that the trace image appears sharply.
- 7) For signal viewing, set the VOLTS/DIV switch and TIME/DIV switch in appropriate positions so that signal waveform is displayed clearly.
- 8) Adjust the ▲ ▼ POSITION and ▲ POSITION controls in appropriate positions so that the displayed waveform is aligned with the graticule and voltage(Vp-p) and period(T) can be read conveniently. The above are the basic operating procedures of the oscilloscope. The above procedures are for single-channel operation with CH 1. Single-channel operation with CH 2 can also be achieved in a similar manner. Further operation methods are explained in the subsequent paragraph.





4.4 Dual-channel Operation

Change the VERT MODE switch to the DUAL states so that trace(CH 2) is also displayed(The explanation in the proceeding section is of CH 1). At this state of procedure, the CH 1 trace is the square wave of the calibrator signal and the CH 2 trace is a straight line since no signal is applied to this channel yet.

Now, apply the calibrator signal to the vertical input terminal of CH 2 with the probe as is the case for CH 1. Set the AC-GND-DC switch to the AC state. Adjust vertical POSITION knobs(11) and (19) so that both channel signals are displayed as shown in Figure4-4.



When ALT/CHOP switch is released (ALT MODE), the input signals applied respectively to CH1 and CH2 appears on the screen alternatively at each sweep. This setting is used when the sweep time is short in 2-channel observation.

When ALT/CHOP switch is engaged (CHOP MODE), the input signals applied to CH1 and CH2 are switched at about 250kHz independent of the sweep and at the same time appear on the screen. This setting is used when the sweep time is long in 2-channel observation.

When in the dual channel operation(DUAL or ADD mode), the CH 1 or CH 2 signal must be selected for the triggering source signal by means of the SOURCE switch. If both CH 1 and CH 2 signals are in a synchronized relationship, both waveforms can be displayed stationary, if not, only the signal selected by the SOURCE switch can be stationary. If the TRIG.ALT push switch is engaged, both waveforms can be displayed stationary.

4.5 ADD Operation

An algebraic sum of the CH 1 and CH 2 signals can be displayed on the screen by setting the VERT MODE switch to the ADD state. The displayed signal is the difference between CH 1 and CH 2 signals if the CH 2 INV push switch is engaged.

For accurate addition or subtraction, it is a prerequisite that the sensitivities of the two channels are adjusted accurately at the same value by means of the VARIABLE knobs. Vertical positioning can be made with the $\Delta \nabla$ POSITION knob of either channel. In view of the linearity of the vertical amplifiers, it is most advantage to set both knobs in their mid-positions.

4.6 Triggering

Proper triggering is essential for efficient operation of an oscilloscope. The user must be thoroughly familiar with the triggering functions and procedures.

(1)Functions of MODE switch:

- AUTO : When the AUTO switch is engaged, automatic sweep operation is selected. in automatic sweep operation, the sweep generator free runs to generate a sweep without a trigger signal. However, it automatically switches to triggered sweep operation if an acceptable trigger source signal is present. The AUTO position is handy when first setting up the scope to observe a waveform, it provides sweep for waveform observation until other controls can properly set. Once the controls are set, operation is often switched back to the NORM triggering mode, since it is more sensitive. Automatic sweep must be used for dc measurements and signals of such low amplitude that they will not trigger the sweep.
- : The NORM switch provides normal triggered sweep operation. The sweep remains at rest until the selected trigger source signal crosses the threshold level set by the TRIG LEVEL control. The trigger causes one sweep to be generated, after which the NORM sweep again remains at rest until triggered. In the NORM position, there will be no trace unless an adequate trigger signal is present. In the ALT mode of dual trace operation with NORM sweep selected, there will be trace unless both channel 1 and 2 signals are adequate for triggering.

- TV-V : Setting the MODE switch to the TV-V position permits selection of vertical sync pulses for sweep triggering when viewing composite video waveforms. Vertical sync pulses are selected as trigger to permit viewing of vertical fields and frames of video. A sweep time of 2 ms/div is appropriate for viewing fields of video and 5 ms/div for complete frames (two interlaced fields) of video.
- TV-H : Setting the MODE switch to the TV-H position permits selection of horizontal sync pulses for sweep triggering when viewing composite video waveforms. Horizontal sync pulses are selected as trigger to permit viewing of horizontal lines of video. A sweep time of about 10 us/div is appropriate for displaying lines of video. The SWP VAR control can be set to display the exact number of waveforms desired.

This oscilloscope synchronizes with only (-) polarity, that is, the sync pulses are negative and the video is positive as shown in Figure 4-5.

(2)Functions of SOURCE switch:

The displayed signal itself or a trigger signal which has a time relationship with the displayed signal is required to be applied to the trigger circuit to display a stationary signal on the CRT screen. The SOURCE switch is used for selecting such a triggering source.

- CH 1 : The internal trigger method which is used most commonly.
- CH 2 The signal applied to the vertical input terminal is branched off from the preamplifier and is fed to the trigger circuit through the VERT MODE switch. Since the triggering signal is the measured signal itself, a stable waveform can be readily displayed on the CRT screen. When in the DUAL or ADD operation, the signal selected by the SOURCE switch is used as the triggering source signal.
- LINE : The AC power line frequency signal is used as the triggering signal. This method is effective when the measured signal has a relationship with the AC line frequency, especially for measurements of low level AC noise of audio equipment, thyristor circuits, etc.
- EXT The sweep is triggered with an external signal applied to the external trigger input terminal. An external signal which has a periodic relationship with respect to the measured signal is used. Since the measured signal is not used as the triggering signal, the waveforms can be displayed more independent than the measured signal.

Figure 4-5.

(3)Functions of TRIG LEVEL control and SLOPE switch :

A sweep trigger is developed when the trigger source signal crosses a preset threshold level. Rotation of the TRIG LEVEL control varies the threshold level. In the + direction, the triggering threshold shifts to a more positive value, and in the - direction, the triggering threshold shifts to a more negative value. When the control is centered, the threshold level is set at the approximate average of the signal used as the triggering source.

The TRIG LEVEL control adjusts the start of the sweep to almost any desired point on a waveform. On sine wave signals, the phase at which sweep begins is variable. Note that if the TRIG LEVEL control is rotated toward its extreme + or - setting, no sweep will be developed in the NORM trigger mode because the triggering threshold exceeds the peak amplitude of the sync signal.

When the TRIG SLOPE switch is set to the (+) position (up), the sweep is developed form the trigger source waveform as it crosses the threshold level in a positive-going direction. When the TRIG SLOPE control is set to the (-) position (down), a sweep trigger is developed from the trigger source waveform as it crosses the threshold level in a negative-going direction. This switch selects the slope (polarity) triggering signal as shown in Figure 4-6.



(4) Function of TRIG ALT switch :

The TRIG ALT switch is used to select alternate triggering and alternate display when the DUAL-trace VERT MODE is selected(the switch has on effect in the CH1, CH2, or ADD modes). In the alternate triggering mode(when dual-trace operation is selected), the trigger source alternates between channel 1 and channel 2 with each sweep. This is convenient for checking amplitudes, waveshape, or waveform period measurements, and even permits simultaneous observation of two waveforms which are not related in frequency or period. However, this setting is not suitable for phase or timing comparison measurements. For such measurements, both traces must be triggered by the same sync signal.

When the CHOP and the TRIG ALT switches are both engaged during dual-trace operation, synchronization of the display is not possible because the chopping signal becomes the trigger. Use the ALT mode by itself, or select CH1 or CH2 as trigger source.

--- 17 ----

4.7 TIME/DIV Control

Set the TIME/DIV control to display the desired number of cycles of the waveform. If there are too many cycles displayed for good resolution, switch to a faster sweep speed. If only a line is displayed, try a slower sweep speed. When the sweep speed is faster than the waveform being observed, only part of it will be displayed, which may appear as a straight line for a square wave or pulse waveform.

4.8 Sweep Magnification

When a certain part of the displayed waveform is needed to be expanded timewise, a faster sweep speed may be used. However, if the required portion is apart from the starting point of the sweep, the required portion may run off the CRT screen. In such a case, push in the $\times 10MAG$ button.

When this has been done, the displayed waveform will be expanded 10 times to the right and left with the center of screen as the center of expansion.

The sweep time during the magnification operation is as follows :

(Value indicated by TIME/DIV switch) x 1/10

Thus, the unmagnified maximum sweep speed (InSec/DIV) can be increased with the magnification as follows :

 $1 \mu \text{Sec/DIV} \times 1/10 = 100 \text{nSec/DIV}$



Figure 4-7

4.9 X-Y Operation

Set the TIME/DIV switch to X-Y position. Then the instrument works as an X-Y oscilloscope. Each input is applied to the instrument as follows. X-axis signal(horizontal axis signal) : CH1 INPUT. Y-axis signal(vertical axis signal) : CH2 INPUT.

Note: When high frequency signals are displayed in the X-Y operation, pay attention to the frequency bandwidths and phase difference between X and Y-axis.



X-Y operation permits the oscilloscope to perform many measurements not possible with conventional sweep operation. The CRT display becomes an electronic graph of two instantaneous voltages. The display may be a direct comparison of the two voltages such as a vectorscope display of video color bar patterns. However, the X-Y mode can be used to graph almost any dynamic characteristic if a transducer is uesd to change the characteristic (frequency, temperature, velocity, etc.) into a voltage. One common application is frequency response measurements, where the Y-axis corresponds to signal amplitude and the X-axis corresponds to frequency.

- 1. Set the TIME/DIV control to the X-Y position (fully counterclockwise). In this mode, channel 1 becomes the X-axis input and channel 2 becomes the Y-axis input.
- 2. The X and Y positions are now adjusted using the horizontal ◀ ▶ POSITION and CH2 △∇ POSITION controls respectively.
- 3. Adjust the amount of vertical (Y-axis) deflection with the CH2 VOLTS/DIV and VAR controls.
- 4. Adjust the amount of horizontal (X-axis) deflection with the CH1 VOLTS/DIV and VAR controls.

4.10 Calibration of Probe

As explained previously, the probe makes up a wide range attenuator. Unless phase compensation is properly done, the displayed waveform is distorted causing measurement errors. Therefore, the probe must be properly compensated before use.

Connect the 10:1 probe BNC to the INPUT terminal of CH1 or CH2 and set VOLTS/DIV switch at 50mV. Connect the probe tip to the calibration voltage output terminal and adjust the compensation trimmer on probe for optimum square wave (minimum overshoot, rounding off and tilt).

Figure 4-9



(a) Correct compensation





(b) Over compensation

(c) Insufficient compensation

4.11 DC BAL Adjustments

The ATT blance of the vertical axis can be made easily.

(1)Set the input couping switches of CH1 and CH2 to GND and set the TRIG MODE to AUTO. Then position the base line to the center. (2)Turn the VLOTS/DIV switch to 5mV-10mV and adjust so that the line does not move.

5.MAINTENANCE

WARNING

The following instructions are for use by qualified personnel only. To avoid electrical shock, do not perform any servicing other than in the operating instructions unless you are qualified to do so.

5.1 Fuse Replacement

If the fuse blows, the power lamp indicators will not light and the oscilloscope will not operate. The fuse should not normally open unless a problem has developed in the unit. Try to determine and correct the cause of the blown fuse. The replace only with a fuse of the correct rating and type(see page 4)

The fuse is located on the rear panel (see fig. 4-2).



WARNING. For continued fire protection. Replace fuse only with 250V fuse of the specified type and rating ,and disconnect power cord before replacing fuse.

5.2 Line Voltage Conversion

The primary winding of the power transformer is tapped to permit operation from 115V, or 230VAC 50/60Hz line voltage Conversion from one line voltage to another is done by changing the line voltage selector switch as shown in Fig. 4-2

The rear panel identifies the line voltage to which the unit was factory set. To convert to a different line voltage, perform the following procedure:

(1)Make sure the power cord is unplugged.

(2)Change the line voltage selector switch to the desired line voltage position.

(3)A change in line voltage may also require a corresponding change of fuse value. Install the correct fuse value as listed on rear panel.

5.3 Cleaning

To clean the oscilloscope, use a soft cloth dampened in a solution of mild detergent and water. Do not spray cleaner directly onto the oscilloscope because it may leak into the cabinet and cause damage.

Do not use chemicals containing benzine, benzene, toluene, xylene, acetone, or similar solvents.

Do not use abrasive cleaners on any portion of the oscilloscope.

6.BLOCK DIAGRAM

